

# MCR-MGT Management Module

## Command Line Interface Guide

Version 1.8

Part #5500311-16

Sept 2014

---

Copyright Statement

This document must not be reproduced in any way whatsoever, either printed or electronically, without the consent of:

Perle Systems Limited,  
60 Renfrew Drive  
Markham, ON  
Canada  
L3R 0E1

Perle reserves the right to make changes without further notice, to any products to improve reliability, function, or design.

Perle Systems Limited, 2010 - 2014.



# Table of Contents

---

<b>Preface .....</b>	<b>9</b>
<b>About This Book .....</b>	<b>9</b>
<b>Intended Audience.....</b>	<b>9</b>
<b>Typeface Conventions.....</b>	<b>9</b>
<b>Chapter 1 Introduction.....</b>	<b>10</b>
<b>CLI Conventions .....</b>	<b>10</b>
Command Syntax .....	10
Command Shortcuts .....	10
Command Options .....	11
<b>Chapter 2 MCR-MGT Module Specific Commands .....</b>	<b>12</b>
<b>MCR-MGT Server Commands.....</b>	<b>12</b>
Set Server.....	12
Show Server.....	13
Set Service .....	13
Set Display Format.....	14
Show Display Format.....	14
<b>SSH Server Commands.....</b>	<b>15</b>
Set SSH-Server .....	15
Show SSH-Server .....	15
<b>Hardware Commands .....</b>	<b>16</b>
Set Console.....	16
Show Console.....	16
Set Ethernet .....	16

---

Show Hardware.....	17
<b>Authentication Commands .....</b>	<b>18</b>
Set authentication .....	18
Set authentication Kerberos.....	18
Set authentication LDAP/Active Directory .....	18
Set authentication NIS .....	20
Set Authentication RADIUS .....	20
Add RADIUS .....	21
Delete RADIUS .....	21
Set Authentication TACACS+.....	21
Set Authentication SecurID .....	22
Show Authentication.....	23
<b>Email Commands .....</b>	<b>24</b>
Set Email-Alert Server.....	24
Show Email-Alert Server.....	25
<b>Dynamic DNS Commands .....</b>	<b>26</b>
Set Dynamic-DNS .....	26
Set Dynamic-DNS SSL .....	26
Set Dynamic-DNS SSL Cipher-Suite.....	28
Show Dynamic-DNS .....	29
<b>IPv6 Commands .....</b>	<b>30</b>
Set IPv6.....	30
Show IPv6.....	30
Add Custom-IPv6 (Set Custom-IPv6).....	30
Delete Custom-IPv6.....	31
<b>Chapter 3 Chassis/slot Commands .....</b>	<b>32</b>
<b>Chassis Commands.....</b>	<b>32</b>
Set Chassis Temperature-Threshold.....	32
Set Chassis serial.....	32
Set Chassis management-module-slot .....	32
Set slot common parameters .....	33
Set slot, power schedule .....	33

---

<b>Slot Control Commands</b> .....	<b>34</b>
Slot reset .....	34
Slot reset to factory .....	34
Slot power .....	34
Slot virtual-cable-test .....	34
Slot loopback .....	34
Slot register read/write .....	34
Slot link-test .....	35
Slot sfp/xfp (read memory) .....	35
<b>Slot Configuration Commands</b> .....	<b>36</b>
Set slot... cm-100 .....	36
Set slot... cm-100mm .....	37
Set slot... cm-1000 .....	37
Set slot... cm-1000mm .....	39
Set slot... cm-110 .....	40
Set slot... cm-1110 .....	45
Set slot... cm-10g .....	50
Set slot... cm-10gt .....	52
Set slot... cm-4gpt .....	54
Set slot... ex .....	55
Show slot * command .....	60
Show slot # command .....	60
Show chassis alerts .....	60
Show chassis details .....	61
<b>Chapter 4 User Commands</b> .....	<b>62</b>
<b>Commands for active sessions</b> .....	<b>62</b>
Admin .....	62
Help .....	62
Logout .....	62
Menu .....	62
Ping .....	62
Screen .....	63
Set Termttype .....	63

---

Syslog Console.....	63
Show Termtypes.....	63
Version .....	63
<b>Configuring Users.....</b>	<b>63</b>
Add User.....	63
Delete User.....	64
Set User .....	64
Show User.....	64
<b>Chapter 5 Network Commands .....</b>	<b>65</b>
<b>SNMP Commands .....</b>	<b>65</b>
Add Community.....	65
Set SNMP.....	65
Set SNMP V3-Security .....	66
Set snmp-trap common .....	66
Set snmp-trap entry.....	66
Set snmp-trap v3 .....	67
Delete Community .....	68
Show SNMP.....	68
<b>Hosts Commands .....</b>	<b>69</b>
Add Host.....	69
Delete Host.....	69
Set Host.....	69
Show Hosts .....	69
Add Authorized Host.....	70
Delete Authorized Host.....	70
Set Authorized Host .....	70
Show Authorized Hosts .....	70
<b>DNS Commands .....</b>	<b>71</b>
Add DNS .....	71
Delete DNS .....	71
Show DNS .....	71
<b>Gateway Commands.....</b>	<b>72</b>

---

Add Gateway .....	72
Delete Gateway .....	72
Set Gateway .....	72
Show Gateways .....	73
<b>Logging Commands .....</b>	<b>74</b>
Set Syslog .....	74
Show Syslog .....	74
Set event-log .....	74
<b>IPv6 Tunnels .....</b>	<b>75</b>
Add IPv6tunnel .....	75
Set IPv6tunnel .....	75
Show IPv6tunnel .....	75
Delete IPv6tunnel .....	75
<b>Chapter 7 Administration Commands .....</b>	<b>76</b>
<b>Administration Commands .....</b>	<b>76</b>
Reboot .....	76
Reset Factory .....	76
Set Firmware auto-update .....	76
Show Firmware auto-update .....	76
Save .....	76
Set Bootup .....	76
Show text-config .....	77
Show Bootup .....	77
<b>TFTP File Transfer Commands .....</b>	<b>78</b>
Netload configuration and firmware .....	78
Netsave configuration .....	78
<b>Keys and Certificates Commands .....</b>	<b>80</b>
Netload keys .....	80
Netsave keys .....	80
Netload Media Converter Modules .....	81
Netload Serialt-buf .....	81
Netload sntp-keys .....	81

---

<b>Chapter 6 Time Commands .....</b>	<b>82</b>
<b>Time Commands .....</b>	<b>82</b>
Set Time.....	82
Set Timezone .....	82
Show Time.....	82
Show Timezone .....	82
<b>SNTP Commands .....</b>	<b>83</b>
Add SNTP .....	83
Delete SNTP .....	83
Set SNTP .....	83
Show SNTP .....	84
Show SNTP-Info.....	84
<b>Time/Date Setting Commands .....</b>	<b>85</b>
Set Date .....	85
Set Summertime .....	85
Set Summertime Fixed.....	85
Set Summertime Recurring .....	85
Show Date .....	86
Show Summertime .....	86
<b>Chapter 8 Statistics Commands .....</b>	<b>87</b>
<b>Configuration Statistics .....</b>	<b>87</b>
Show Interface .....	87
<b>Run-Time Statistics .....</b>	<b>87</b>
Delete Arp.....	87
Show Arp.....	87
Uptime .....	87



# Preface

---

## About This Book

This guide provides the information you need to:

- configure the MCR-MGT Management Module using the Command Line Interface (CLI)

## Intended Audience

This guide is for administrators who will be configuring the MCR-MGT Management Module. Some prerequisite knowledge is needed to understand the concepts and examples in this guide:

- If you are using an external authentication application(s), working knowledge of the authentication application(s).
- Knowledge of TFTP the transfer protocols the MCR-MGT Management Module uses.

## Typeface Conventions

Most text is presented in the typeface used in this paragraph. Other typefaces are used to help you identify certain types of information. The other typefaces are:

Typeface Example	Usage
At the C: prompt, type: <code>add host</code>	This typeface is used for code examples and system-generated output. It can represent a line you type in, or a piece of your code, or an example of output.
Set the value to <b>TRUE</b> .	The typeface used for <b>TRUE</b> is also used when referring to an actual value or identifier that you should use or that is used in a code example.
<code>subscribe <i>project</i> <i>subject</i></code>  <code>run <b>yourcode</b>.exec</code>	The italicized portion of these examples shows the typeface used for variables that are placeholders for values you specify. This is found in regular text and in code examples as shown. Instead of entering <i>project</i> , you enter your own value, such as <i>stock_trader</i> , and for <b>yourcode</b> , enter the name of your program.
<i>MCR-MGT Management Module User's Guide</i>	This typeface indicates a book or document title.
See <b>About This Book</b> on page 9 for more information.	This indicates a cross-reference to another chapter or section that you can click on to jump to that section.



# Introduction

---

## CLI Conventions

This section explains how to interpret the CLI syntax. Not all CLI commands are available on all product models.

### Command Syntax

Each command is broken down into several categories:

- **Description**—Provides a brief explanation of how the command is used.
- **User Level**—Shows which user level(s) (Operator and/or Admin) can issue the command.
- **Syntax**—Shows the actual command line options. The options can be typed in any order on the command line. The syntax explanation will use the following command to break down the command syntax:

```
set service [telnetd on|off] [sshd on|off] [httpd on|off]
[httpsd on|off] [snmpd on|off] [setip on|off]
```

- Square brackets ([]) show the options that are available for the command. You can type a command with each option individually, or string options together in any order you want. For example,  
**set service sshd on telnetd off**
- Angle brackets (<>) show that the text inside the brackets is a description for a variable value that you must fill in according to your requirements. In the **set server** command, you must determine the values for **domain**, **internet**, **name**, **password-limit**, and **subnet-bit-length**, if you wish to specify them and not use their defaults (default values provided in the **Options** description). The angle brackets can also contain a range that can be used.
- The pipe (|) shows an 'or' condition. For example, valid values for **telnetd** are either **on** or **off**.
- **Options**—Provides an explanation of each of the options for a command and the default value if there is one. Some commands do not have any options, so this category is absent.

### Command Shortcuts

When you type a command, you can specify the shortest unique version of that command or you can press the **ESC** or **TAB** key to complete the command. For example, the following command:

```
set ethernet crossover auto
```

can be typed as:

```
set eth cro a
```

or, you can use the **ESC** key to complete the lines as you go along:

```
set eth<ESC>ernet cr<ESC>osserver a<ESC>uto
```

where the **ESC** key was pressed to complete the option as it was typed.

## Command Options

When you are typing commands on the command line (while connected to the MCR-MGT Management Module), you can view the options by typing a question mark (**?**), **ESC**, or **TAB** key after any part of the command to see what options are available/valid. For example:

```
MCR-MGT-100903#set console ?
data-bits
flow
mode
monitor-dsr
parity
speed
stop-bits
MCR-MGT-100903#set console mode ?
disabled
enabled
MCR-MGT-100903#set console mode enabled ?
data-bits
flow
mode
monitor-dsr
parity
speed
stop-bits
Or press <ENTER> to confirm command
MCR-MGT-100903#set console mode enabled
MCR-MGT-100903#
```



# MCR-MGT Module Specific Commands

## MCR-MGT Server Commands

### Set Server

<b>Description</b>	Sets high level parameters for the MCR-MGT Management Module.
<b>User Level</b>	Admin
<b>Syntax</b>	<pre>set server [auto-obtain-dns] [auto-obtain-gw] [dhcp-update-dns] [domain &lt;text&gt;] [name &lt;text&gt;] [incoming-pings enabled disabled] [internet dhcp/bootp on off &lt;ipv4-address&gt;] [netmask &lt;ipv4-address&gt;] [session-timeout &lt;number in seconds&gt;] tftp] [ssl-passphrase &lt;text&gt;]</pre>
<b>auto-obtain-dns</b>	When DHCP/BOOTP is enabled, the MCR-MGT Management Module will receive the DNS IP address from the DHCP/BOOTP server.
<b>auto-obtain-gw</b>	When DHCP/BOOTP is enabled, the MCR-MGT Management Module will receive the Default Gateway IP address from the DHCP/BOOTP server.
<b>dhcp-update-dns</b>	When this parameter is set, the MCR-MGT Management Module will provide the DHCP server with a fully qualified domain name (FQDN), so that the DHCP server can update the network's DNS server with the newly assigned IP address. <b>Default:</b> Disabled
<b>domain</b>	This field is combined with the <b>System Name</b> to construct the fully qualified domain name (FQDN). For example, if the domain is <b>mycompany.com</b> and the <b>Server Name</b> is set to <b>accounting</b> , the FQDN would be <b>accounting.mycompany.com</b> .
<b>incoming-pings</b>	The MCR-MGT management module will respond to incoming pings. <b>Default:</b> Enabled
<b>name</b>	The <b>System Name</b> is used for informational purposes by such tools as the MCR Web Manager and is also used in conjunction with the Domain field to construct a fully qualified domain name (FQDN). <b>Default:</b> MCR-MGT-xxxxxx (where xxxxxx is the last 6 digits of the Management Module's MAC address).
<b>internet</b>	This option accepts one of two parameters, ipv4 address or dhcp/bootp. ipv4 address - this parameter is followed by the IP address you wish to set for the Ethernet interface on the MCR-MGT Management Module. dhcp/bootp - this parameter is followed by an "on" or "off" directive. It enables or disables the use of DHCP as a method for obtaining the IP information for the Ethernet port of the MCR-MGT Management Module.
<b>netmask</b>	The IPv4 subnet mask you wish to assign to the MCR-MGT management module's Ethernet port. For example, 255.255.0.0

<b>session- timeout</b>	The session inactivity timer is only used when “Bypass login” is not enabled (i.e. login is required). If no activity is detected on the session for the amount of time configured here in seconds, the session will be terminated. The default timeout is 3600 seconds (60 minutes)
<b>tftp</b>	This option takes up to two parameters, retry and timeout. Retry is the number of times the Management Module will retry to transmit a TPFT packet to/from a host when no response is received. Enter a value between 0 and 5. The default is <b>5</b> . A value of <b>0</b> (zero) means no retry. Timeout, in seconds, that the Management Module will wait for a successful transmit or receipt of TFTP packets before retrying a TFTP transfer. Enter a value between 3 and 10. The default is <b>3</b> seconds.
<b>ssl-passphrase</b>	This is the SSL/TLS passphrase used to generate an encrypted RSA/DSA private key. This private key and passphrase are required for both HTTPS and SSL/TLS connections, unless an unencrypted private key was generated, then the SSL passphrase is not required. Make sure that you download the SSL private key and certificate if you are using the secure HTTP option (HTTPS) or SSL/TLS. If both RSA and DSA private keys are downloaded to the MCR-MGT Management Module, they need to be generated using the same SSL passphrase for both to work.

## Show Server

<b>Description</b>	Shows the parameters set for the server.
<b>User Level</b>	Admin, Operator
<b>Syntax</b>	<b>show server</b>

## Set Service

<b>Description</b>	Enables or disables the given service on the MCR-MGT Management Module. If disabled, the module does not listen for connections on that service.
<b>User Level</b>	Admin
<b>Syntax</b>	<b>set service [telnetd] [sshd] [httpd] [httpsd] [snmpd] [setip]</b> For each service above, you can enter "on" or "off" to enable or disable the service.

## Set Display Format

<b>Description</b>	Configures the display preferences for a number of items.
<b>User Level</b>	Admin
<b>Syntax</b>	<b>set display-format</b> [date] [temperature] [time] [sfp-power]
<b>date</b>	The Date can be express in the following formats: <ul style="list-style-type: none"> <li>● MM/DD/YYYY</li> <li>● DD/MM/YYYY</li> <li>● YYYY-MM-DD</li> </ul> <b>Default:</b> MM/DD/YYYY
<b>temperature</b>	Temperature can be expressed as Celsius or Fahrenheit.
<b>time</b>	Time can be express in the following formats: <ul style="list-style-type: none"> <li>● 12-Hour Clock</li> <li>● 24-Hour Clock</li> </ul> <b>Default:</b> 12-Hour Clock
<b>sfp-power</b>	Power can be expressed in mW(milliwatts) or dBm (decibel milliwatts) for SFP modules.

## Show Display Format

<b>Description</b>	shows the display preferences.
<b>User Level</b>	Admin, Operator
<b>Syntax</b>	<b>show display-format</b> Shows the format for Date, Time, Temperature and SFP module.

# SSH Server Commands

## Set SSH-Server

See *Keys and Certificates* in the *MCR-MGT Management User's Guide* for information about the keys and certificates that need to be uploaded or downloaded with the MCR-MGT Management Modules SSH server.

<b>Description</b>	Configures the MCR-MGT Management Modules SSH server.
<b>User Level</b>	Admin
<b>Syntax</b>	<b>set ssh-server</b> [authentication [RSA[on off] [ DSA on off]   [keyboard-interactive on off] [password on off] [compression on off] [verbose on off]] [ssh1 on off] [cipher 3DES Blowfish AES Cast Arcfour]
<b>authentication</b>	Defines the authentication method to be used by the MCR-MGT Management Module's SSH server. The valid options are; RSA DSA Keyboard-interactive Password. - (only valid for SSH1). You can select one or more options. The authentication method is followed by "on" or "off" to enable or disable this authentication method.
<b>compression</b>	This parameter enables or disables compression. Typically compression is not required on fast networks (may actually slow things down). The valid options are; On - turn compression on. Off - turn compression off.
<b>verbose</b>	Displays debug messages on the terminal. On - turn on debug. Off - turn off debug.
<b>ssh1</b>	Allows the user's client to negotiate an SSH-1 connection, in addition to SSH-2. On - turn on ssh1. Off - turn off ssh1.
<b>cipher</b>	This parameter defines the ciphers which will be negotiated with the client. The following ciphers can be enabled; 3DES Blowfish AES Cast Arcfour You can select one or more options. The cipher is followed by "on" or "off" to have it included or not included in the negotiated list.

## Show SSH-Server

<b>Description</b>	Shows the SSH server settings.
<b>User Level</b>	Admin, Operator
<b>Syntax</b>	<b>show ssh-server</b>

# Hardware Commands

## Set Console

<b>Description</b>	Sets the operating parameters of the console port.
<b>User Level</b>	Admin
<b>Syntax</b>	<code>set console [flow soft hard both] [speed 9600 19200 38400 57600 115200] [data-bits 7 8] [mode enabled disabled] [monitor-dsr on off] [stop-bits 1 2] [parity even odd none]</code>
<b>Flow</b>	Defines whether the data flow control is handled by using software ( <b>Soft</b> ), hardware ( <b>Hard</b> ), software and hardware ( <b>Both</b> ) or no flow control at all ( <b>None</b> ).
<b>Speed</b>	Specifies the baud rate of the serial console port. <b>Data Options:</b> 9600, 19200, 38400, 57600 or 115200 <b>Default:</b> 9600
<b>Data-bits</b>	Specifies the number of bits in a transmitted character. <b>Data Options:</b> 7, 8 <b>Default:</b> 8
<b>Mode</b>	<b>Enables/Disables the serial console port.</b> <b>Default:</b> Enabled
<b>Monitor-dsr</b>	Specifies whether the EIA-232 signal DSR (Data Set Ready) should be monitored. on the serial console port. When the DSR signal is dropped (turn off terminal), the session is terminated. If login is required, will force user to login next time terminal is powered up. <b>Default:</b> Off
<b>Stop-bits</b>	Specifies the number of stop bits that follow a byte. <b>Data Options:</b> 1, 2 <b>Default:</b> 1
<b>Parity</b>	Specifies the type of parity being used for the data communication on the serial port. <b>Data Options:</b> Even, Odd, None <b>Default:</b> None

## Show Console

<b>Description</b>	Displays the configured parameters of the console port.
<b>User Level</b>	Admin, Operator
<b>Syntax</b>	<code>show console</code>

## Set Ethernet

<b>Description</b>	Sets the hardware configuration for the Ethernet port(s).
<b>User Level</b>	Admin
<b>Syntax</b>	<code>set ethernet [crossover] [speed-and-duplex]</code>

<b>crossover</b>	<p>This options sets the method by which the Ethernet's cable polarity will be set. The following options are available;</p> <ul style="list-style-type: none"> <li>● <b>Auto</b>— automatically detects the Ethernet's cable polarity</li> <li>● <b>MDI</b> —the cable's polarity is straight-through</li> <li>● <b>MDI-X</b> —the cable's polarity is crossovered</li> </ul> <p>The default setting for this parameter is "Auto"</p>
<b>speed-and-duplex</b>	<p>Define the Ethernet connection.</p> <p><b>Data Options:</b></p> <ul style="list-style-type: none"> <li>● <b>Auto</b>—automatically detects the Ethernet interface speed and duplex</li> <li>● 10 Mbps/Half Duplex</li> <li>● 10 Mbps/Full Duplex</li> <li>● 100 Mbps/Half Duplex</li> <li>● 100 Mbps/Full Duplex</li> <li>● 1000 Mbps/Half Duplex</li> </ul> <p><b>Default:</b> Auto</p>

## Show Hardware

<b>Description</b>	Shows the hardware resources, Ethernet link status, date and time.
<b>User Level</b>	Admin, Operator
<b>Syntax</b>	<b>show hardware</b>

# Authentication Commands

## Set authentication

<b>Description</b>	Sets the authentication method for the MCR-MGT Management Module.
<b>User Level</b>	Admin
<b>Syntax</b>	<code>set authentication [type primary secondary raduis kerberos ldap nis securid tacacs+ none] [bypass-login on off] [secondary-as-backup disabled enabled]</code>
<b>type</b>	<p>You can define up to two authentication methods which will be used to grant access to users accessing the MCR-MGT Management Module. The type parameter defines which method is used first as well as the type of authentication associated with that method.</p> <p>The first parameter for type is the designation of "primary" or "secondary". The "primary" authentication method is the one that the MCR-MGT Management Module attempts first. If a secondary method is also defined, it may or not be used depending on the setting of the "secondary-as-backup" parameter.</p> <p>The next parameter after the "primary" or "secondary" will be the authentication type. The following types can be specified.</p> <p>radius, kerberos, ldap, nis, securid, tacacs+ or none.</p>
<b>bypass-login</b>	<p>This defines whether users accessing the MCR-MGT Management Module will be required to login before gaining access the unit. The next parameter is as follows;</p> <p>on - users will be required to login.</p> <p>off - users will not be required to login.</p>
<b>secondary-as-backup</b>	<p>If this option is selected (enabled), the secondary authentication method will only be attempted if the MCR-MGT module can not reach the primary authentication host. (i.e. if the primary authentication host indicates that the user does not have access, the secondary authentication method will not be attempted). In other words, the secondary is only used as a backup to the primary in case the primary is not available.</p> <p>If this options is not selected (disabled), the secondary authentication will always be tried if the primary authentication is not successful (for any reason including an indication from the primary that the user is not authenticated).</p> <p><b>Default:</b> Disabled (not selected).</p>

## Set authentication Kerberos

<b>Description</b>	Configures Kerberos authentication settings.
<b>User Level</b>	Admin
<b>Syntax</b>	<code>set authentication kerberos [kdc-domain &lt;text&gt;] [port &lt;number&gt;] [realm &lt;text&gt;]</code>
<b>kdc-domain</b>	The name of a host running the KDC (Key Distribution Center) for the specified realm. The host name that you specify must either be defined in the MCR-MGT Management Module's <b>Host Table</b> before the last reboot or be resolved by DNS.
<b>port</b>	The port that the Kerberos server listens to for authentication requests. <b>Default:</b> 88
<b>realm</b>	The Kerberos realm is the Kerberos host domain name, in upper-case letters.

## Set authentication LDAP/Active Directory

<b>Description</b>	Configures LDAP/Active Directory authentication settings.
<b>User Level</b>	Admin

<b>Syntax</b>	<code>set authentication ldap [base] [client append-base authenticate name password] [encrypt-password] [host] [port] [tls] [tls-port] [user-attribute other sAMAccountName uid]</code>
<b>base</b>	The domain component (dc) that is the starting point for the search for user authentication.
<b>client</b>	Enables/disables appending the base domain component (dc) to the client name field. Enables/disables whether the MCR-MGT Management Module will authenticate itself to the LDAP Server. The name to be used by the MCR-MGT Management Module to authenticate to the LDAP Server. The password to be used when authenticating to the LDAP Server
<b>encrypt-password</b>	When followed by the "MD5" parameter, the MCR-MGT Management Module will encrypt the user's and the MCR-MGT Management Module password strings using MD5 digest. If followed by "none", no encryption will be performed.
<b>host</b>	The name or IP address of the LDAP/Microsoft Active Directory host. If you use a host name, that host must either have been defined in the MCR-MGT Management Module's <b>Host Table</b> before the last reboot or be resolved by DNS. If you are using <b>TLS</b> , you must enter the same string you used to create the LDAP certificate that resides on your LDAP/Microsoft Active Directory server.
<b>port</b>	The port that the LDAP/Microsoft Active Directory host listens to for authentication requests. <b>Default:</b> 389
<b>tls</b>	Enables/disables the Transport Layer Security (TLS) with the LDAP/Microsoft Active Directory host. <b>Default:</b> Disabled.
<b>tls-port</b>	Specify the port number that LDAP/Microsoft Active Directory will use for <b>TLS</b> . <b>Default:</b> 636
<b>user-attribute</b>	This defines the name of the attribute used to communicate the user name to the server. <b>Options:</b> <ul style="list-style-type: none"> <li>● <b>OpenLDAP(uid)</b>—Chose this option if you are using an OpenLDAP server. The user attribute on this server is "uid".</li> <li>● <b>Microsoft Active Directory(sAMAccountName)</b>—Chose this option if your LDAP server is a Microsoft Active Directory server. The user attribute on this server is "sAMAccountName".</li> <li>● <b>Other</b>—If you are running something other than a OpenLDAP or Microsoft Active Directory server, you will have to find out from your system administrator what the user attribute is and enter it in this field.</li> </ul> <b>Default:</b> OpenLDAP(uid)

## Set authentication NIS

<b>Description</b>	Sets NIS authentication parameters.
<b>User Level</b>	Admin
<b>Syntax</b>	<code>set authentication nis [domain] [primary] [secondary]</code>
<b>domain</b>	The NIS domain name.
<b>primary</b>	The primary NIS host that is used for authentication. <b>Default:</b> None
<b>secondary</b>	The secondary NIS host that is used for authentication, should the primary NIS host fail to respond. <b>Default:</b> None

## Set Authentication RADIUS

<b>Description</b>	Sets RADIUS parameters.
<b>User Level</b>	Admin
<b>Syntax</b>	<code>set authentication radius [accounting] acct-authenticator] [acct-port] [auth-port] attributes [nas-identifier nas-ip-address nas-ipv6-address] [retry] [timeout]</code>
<b>accounting</b>	Enables/disables RADIUS accounting. <b>Default:</b> Disabled
<b>acct-authenticator</b>	Enables/disables whether or not the MCR-MGT Management Module validates the RADIUS accounting response. <b>Default:</b> Enabled
<b>acct-port</b>	The port that the RADIUS host listens to for accounting requests. <b>Default:</b> 1813
<b>auth-port</b>	The port that the RADIUS host listens to for authentication requests. <b>Default:</b> 1812
<b>attributes</b>	
<b>nas-identifier</b>	This is the string that identifies the Network Address Server (NAS) that is originating the Access-Request to authenticate a user. <b>Field Format:</b> Maximum 31 characters, including spaces
<b>nas-ip-address</b>	When enabled, the MCR-MGT Management Module will send the MCR-MGT Management Module's Ethernet IPv4 address to the RADIUS server. <b>Default:</b> Enabled
<b>nas-ipv6-address</b>	When enabled, the MCR-MGT Management Module will send the specified IPv6 address to the RADIUS server. <b>Default:</b> Disabled
<b>retry</b>	The number of times the MCR-MGT Management Module tries to connect to the RADIUS server before erroring out. <b>Range:</b> 0-255 <b>Default:</b> 5

<b>timeout</b>	The time, in seconds, that the MCR-MGT Management Module waits to receive a reply after sending out a request to a RADIUS accounting or authentication host. If no reply is received before the timeout period expires, the MCR-MGT Management Module will retry the same host up to and including the number of retry attempts. <b>Range:</b> 1-255 <b>Default:</b> 3 seconds
----------------	--

## Add RADIUS

<b>Description</b>	Adds an accounting or authentication RADIUS host.
<b>User Level</b>	Admin
<b>Syntax</b>	<b>add radius [accounting-host] [auth-host]</b>
<b>accounting-host</b>	The first time this command is entered, this is the name of the primary RADIUS accounting host.  The second time this command is entered, this is the name of the secondary RADIUS accounting host.
<b>auth-host</b>	The first time this command is entered, this is the name of the primary RADIUS authentication host.  The second time this command is entered, this is the name of the secondary RADIUS authentication host, should the first RADIUS host fail to respond.
<b>secret</b>	For both of the above, you can specify the "secret" associated with each host. The secret is the password which is shared between the MCR-MGT Management Module and the RADIUS host.  After typing the command <b>secret</b> and pressing <b>Enter</b> , you will be prompted to enter the secret and then re-enter the secret.

## Delete RADIUS

<b>Description</b>	Deletes an accounting or authentication RADIUS host.
<b>User Level</b>	Admin
<b>Syntax</b>	<b>delete radius [accounting] [authentication]</b>
<b>accounting</b>	Deletes the specified accounting host from the RADIUS authentication settings.
<b>authentication</b>	Deletes the specified authentication host from the RADIUS authentication settings.

## Set Authentication TACACS+

<b>Description</b>	Configures TACACS+ authentication settings.
<b>User Level</b>	Admin
<b>Syntax</b>	<b>set authentication tacacs+ [port] [primary] [secondary] [secret] [alternate-service-names] [authorization] [accounting] [acct-port] [acct-primary] [acct-secondary] [acct-secret]</b>
<b>port</b>	The port number that TACACS+ listens to for authentication requests. <b>Default:</b> 49
<b>primary</b>	The primary TACACS+ host that is used for authentication. <b>Default:</b> None
<b>secondary</b>	The secondary TACACS+ host that is used for authentication, should the primary TACACS+ host fail to respond. <b>Default:</b> None

<b>secret</b>	The TACACS+ shared secret is used to encrypt/decrypt TACACS+ packets in communications between two devices. The shared secret may be any alphanumeric string. Each shared secret must be configured on both client and server sides.
<b>secret</b>	The TACACS+ shared secret is used to encrypt/decrypt TACACS+ packets in communications between two devices. The shared secret may be any alphanumeric string. Each shared secret must be configured on both client and server sides.
<b>alternate-service-names</b>	The TACACS+ service name for Telnet or SSH is normally “raccess”. The service name for MCR Web Manager is “EXEC”. In some cases, these service names conflicted with services used by Cisco devices. If this is the case, checking this field will cause the service name for Telnet or SSH to be “perlecli” and the service name for MCR Web Manager to be “perleweb”.
<b>accounting</b>	Enables/disables TACACS+ accounting. <b>Default:</b> Disabled
<b>acct-port</b>	The port number that TACACS+ listens to for accounting requests. <b>Default:</b> 49
<b>acct-primary</b>	The primary TACACS+ host that is used for accounting. <b>Default:</b> None
<b>acct-secondary</b>	The secondary TACACS+ host that is used for accounting, should the primary accounting TACACS+ host fail to respond. <b>Default:</b> None
<b>acct-secret</b>	The TACACS+ shared secret is used to encrypt/decrypt TACACS+ packets in communications between two devices. The shared secret may be any alphanumeric string. Each shared secret must be configured on both client and server sides.

## Set Authentication SecurID

<b>Description</b>	Configures SecurID authentication settings.
<b>User Level</b>	Admin
<b>Syntax</b>	<pre>set authentication securid [primary host] [port] [encryption] [legacy]  set authentication securid [replica host] [port] [encryption] [legacy]  set authentication securid reset secret</pre>
<b>primary host</b>	The first SecurID server that is tried for user authentication. <b>Default:</b> None
<b>replica host</b>	If the first SecurID server does not respond to an authentication request, this is the next SecurID server that is tried for user authentication. <b>Default:</b> None
<b>port</b>	The port number that SecurID listens to for authentication requests. <b>Default:</b> 5500
<b>encryption</b>	The type of encryption that will be used for SecurID server communication. <b>Data Options:</b> DES, SDI <b>Default:</b> SDI

<b>legacy</b>	If you are running SecurID 3.x or 4.x, you need to run in <b>Legacy Mode</b> . If you are running SecurID 5.x or above, do not select <b>Legacy Mode</b> . <b>Default:</b> Disabled
<b>reset secret</b>	Resets the SecurID secret (password) in the MCR-MGT Management Module.

## Show Authentication

<b>Description</b>	Shows the authentication settings. If you type just the <b>show authentication</b> command, the configured primary and secondary authentication methods are displayed.
<b>User Level</b>	Admin, Operator
<b>Syntax</b>	<b>show authentication radius ldap tacacs+ nis kerberos securid</b>
<b>Option</b>	<b>radius ldap tacacs+ nis kerberos securid</b> Displays the authentication settings for the specified authentication method.

# Email Commands

## Set Email-Alert Server

<b>Description</b>	Configures email alert settings for the server.
<b>User Level</b>	Admin
<b>Syntax</b>	<code>set email-alert server [from] [domain] [encryption] [level emergency alert critical error warning notice info debug] [mode] [to] [reply-to] [smtp-host] [password] [tcp-port] [username] [verify-peer] [subject]</code>
<b>from</b>	This will be the contents of the from field in the generated email. This field can contain an email address that might identify the Management Module name or some other value.
<b>Domain</b>	This field is only used if SPA authentication is performed with the email server. It may or may not be required. If the email server does not expect this field, it can be left blank.
<b>Encryption</b>	Choose the type of encryption desired. Valid options are; None - All information is sent in the clear. <ul style="list-style-type: none"> <li>● TLS - Select this if your email server requires TLSAll data from previous connections on that serial port has drained</li> <li>● SSL - Select this if your email server requires SSL</li> </ul>
<b>level</b>	Choose the alert level that will trigger an email notification to be sent out. <b>Data Options:</b> <ul style="list-style-type: none"> <li>● System-level Fault</li> <li>● Module Level Fault</li> <li>● Persistent Error</li> <li>● One-time error</li> <li>● Significant Event</li> <li>● Normal Operation.</li> </ul> The level selected is the minimum trigger level with the "Normal Operation" being the least severe and "System-level Fault" being the most severe. The level selected will include alerts of that level and all more severe levels above it. <b>Default:</b> System-level Fault
<b>mode</b>	Enables/disables Email Alerts. <b>Default:</b> Disabled
<b>to</b>	An email address or list of email addresses that will receive the email notification.
<b>reply-to</b>	The email address to whom all replies to the email notification should go.
<b>smtp-host</b>	The SMTP host (email server) that will process the email notification request. This can be either a host name defined in the MCR-MGT Management Module host table or the SMTP host IP address.
<b>password</b>	Enter the password associated with the user configured in "Username". Maximum size of password is 64 characters.
<b>tcp-port</b>	This is the TCP port used to communicate with the email server. <b>Default:</b> 25 for non-SSL, 465 if SSL/TLS is used

---

<b>username</b>	If your mail server requires you to authenticate with it before it will accept email messages, use this field to configure the authorized user name. Maximum size of user name is 64 characters.
<b>verify-peer</b>	<p>When checked this will enable the validation of the certificate presented by the email server. To validate the certificate, you will need to download the appropriate CA list into the Management Module. If the certificate is not found to be valid, the communication with the email server will be terminated. No authentication will take place and the email message will not be forwarded to the email server. If this option is not checked, the certificate validation will still be attempted but if it fails, a syslog message will be generated but the authentication and forwarding of the email will still take place.</p> <p><b>Default:</b> Enabled if SSL or TLS encryption is selected. Disabled if no encryption is selected.</p>
<b>subject</b>	<p>A text string, which can contain spaces, that will display in the <b>Subject</b> field of the email notification.</p> <p>If the text string contains spaces, enclose the string in quotes.</p>

## Show Email-Alert Server

<b>Description</b>	Shows how the server email alert is configured.
<b>User Level</b>	Admin, Operator
<b>Syntax</b>	<code>show email-alert server</code>

# Dynamic DNS Commands

## Set Dynamic-DNS

<b>Description</b>	Configures the dynamic DNS parameters.
<b>User Level</b>	Admin
<b>Syntax</b>	<b>set dynamic-dns</b> [on off] [connection-method] [hostname] [username] [password] [system-type] [wildcard]
<b>on   off</b>	Enables/disables the dynamic DNS feature. When <b>Dynamic DNS</b> is enabled, the MCR-MGT Management Module will automatically update its IP address with DynDNS.org if it changes. <b>Default:</b> Disabled
<b>hostname</b>	Specify the registered hostname with DynDNS.org that will be updated with the MCR-MGT Management Module's IP address should it change. Put in the full name; for example, mymediaconverter.dyndns.org.
<b>username</b>	Specify the user name used to access the account set up on the DynDNS.org server.
<b>password</b>	Specify the password used to access the account set up on the DynDNS.org server.
<b>system-type</b>	Specify how your account IP address schema was set up with DynDNS.org. Refer to www.DynDNS.org for information about this parameter. <b>Data Options:</b> Dynamic, Static, Custom <b>Default:</b> Dynamic
<b>wildcard</b>	Specifies whether to add an alias such as <b>*to your Registered Host Name .yourcompanySCS.dyndns.org</b> pointing to the same IP address as entered for <b>yourcompanySCS.dyndns.org</b> . <b>Data Options:</b> Enable, Disable, Nochange <b>Default:</b> Enable

## Set Dynamic-DNS SSL

<b>Description</b>	Sets the SSL/TLS parameters for the connection between the MCR-MGT Management Module and the DNS server.
<b>User Level</b>	Admin
<b>Syntax</b>	<b>set dynamic-dns ssl</b> [verify-peer] [validation-criteria] [cipher-suite]
<b>verify-peer</b>	Enable this option when you want the Validation Criteria to match the Peer Certificate for authentication to pass. If you enable this option, you need to download an SSL/TLS certificate authority (CA) list file to the MCR-MGT Management Module.

**validation-criteria** Any values that are entered in the validation criteria must match the peer certificate for an SSL connection; any fields left blank will not be validated against the peer certificate. The following validation criteria can be set;

**country** - A two character country code; for example, US. This field is case sensitive in order to successfully match the information in the peer SSL/TLS certificate.

**state-province** -Up to a 128 character entry for the state/province; for example, IL. This field is case sensitive in order to successfully match the information in the peer SSL/TLS certificate.

**locality** - Up to a 128 character entry for the location; for example, a city. This field is case sensitive in order to successfully match the information in the peer SSL/TLS certificate.

**organization** - Up to a 64 character entry for the organisation; for example, Accounting. This field is case sensitive in order to successfully match the information in the peer SSL/TLS certificate.

**organization-unit** - Up to a 64 character entry for the unit in the organisation; for example, Payroll. This field is case sensitive in order to successfully match the information in the peer SSL/TLS certificate.

**common-name** - Up to a 64 character entry for common name; for example, the host name or fully qualified domain name. This field is case sensitive in order to successfully match the information in the peer SSL/TLS certificate.

**email** - Up to a 64 character entry for an email address; for example, acct@anycompany.com. This field is case sensitive in order to successfully match the information in the peer SSL/TLS certificate.

## Set Dynamic-DNS SSL Cipher-Suite

<b>Description</b>	Sets the SSL/TLS cipher suite parameters for the connection between the MCR-MGT Management Module and the DNS server.
<b>User Level</b>	Admin
<b>Syntax</b>	<pre>set dynamic-dns ssl cipher-suite [option1 option2 option3 option4 option5] [encryption] [min-key-size] [max-key-size] [key-exchange] [hmac]</pre>
<b>option1-option5</b>	Sets the priority of the cipher suite, with <b>option1</b> being highest priority and <b>option5</b> lowest priority.
<b>encryption</b>	<p>Select the type of encryption that will be used for the SSL connection:</p> <ul style="list-style-type: none"> <li>● Any—Will use the first encryption format that can be negotiated.</li> <li>● AES</li> <li>● 3DES</li> <li>● DES</li> <li>● ARCFOUR</li> <li>● ARCTWO</li> <li>● None—Removes any values defined for the cipher option.</li> </ul> <p>The default value is Any.</p>
<b>min-key-size</b>	<p>The minimum key size value that will be used for the specified encryption type. Valid options are;</p> <p>40, 56, 64, 128, 168 or 256</p> <p>The default is 40.</p>
<b>max-key-size</b>	<p>The maximum key size value that will be used for the specified encryption type. The Valid options are;</p> <p>40, 56, 64, 128, 168 or 256</p> <p>The default is 256.</p>
<b>key-exchange</b>	<p>The type of key to exchange for the encryption format:</p> <ul style="list-style-type: none"> <li>● <b>Any</b>—Any key exchange that is valid is used (this does not, however, include ADH keys).</li> <li>● <b>RSA</b>—This is an RSA key exchange using an RSA key and certificate.</li> <li>● <b>EDH-RSA</b>—This is an EDH key exchange using an RSA key and certificate.</li> <li>● <b>EDH-DSS</b>—This is an EDH key exchange using a DSA key and certificate.</li> <li>● <b>ADH</b>—This is an anonymous key exchange which does not require a private key or certificate. Choose this key if you do not want to authenticate the peer device, but you want the data encrypted on the SSL/TLS connection.</li> </ul> <p>The default is <b>Any</b>.</p>
<b>hmac</b>	<p>Select the key-hashing for message authentication method for your encryption type:</p> <ul style="list-style-type: none"> <li>● Any</li> <li>● MD5</li> <li>● SHA1</li> </ul> <p>The default is Any.</p>

## Show Dynamic-DNS

<b>Description</b>	Shows the dynamic DNS settings.
<b>User Level</b>	Admin, Operator
<b>Syntax</b>	<code>show dynamic-dns</code>

# IPv6 Commands

## Set IPv6

<b>Description</b>	Configures the basic IPv6 settings.
<b>User Level</b>	Admin
<b>Syntax</b>	<b>set ipv6</b> [ <b>dhcpv6-settings</b> ] [ <b>enable-ipv6-addressing</b> ] [ <b>auto-obtain-dns-ipv6</b> ]
<b>dhcpv6-settings</b>	Determines the types of information that the MCR-MGT Management Module will accept from the DHCPv6 server, IPv6 address(es) and/or network prefix(es). <b>ipv6-address</b> - When enabled, the MCR-MGT Management Module will accept IPv6 address(es) from the DHCPv6 server. This is <code>off</code> by default. <b>network-prefix</b> - When enabled, the MCR-MGT Management Module will accept the network prefix from the DHCPv6 server. This is <code>off</code> by default.
<b>enable-ipv6-addressing</b>	When enabled, you can configure the MCR-MGT Management Module to obtain the IPv6 address(es) using IPv6 Autoconfiguration or a DHCPv6 server. Default: Enabled
<b>auto-obtain-dns-ipv6</b>	Enable or disable whether the MCR-MGT Management Module will obtain the DNS IPv6 address from the DHCPv6 server.

## Show IPv6

<b>Description</b>	Shows the IPv6 settings.
<b>User Level</b>	Admin, Operator
<b>Syntax</b>	<b>show ipv6</b>

## Add Custom-IPv6 (Set Custom-IPv6)

<b>Description</b>	
<b>User Level</b>	Admin
<b>Syntax</b>	<b>add custom-ipv6 method</b> [ <b>auto</b> ] [ <b>network-prefix</b> ] [ <b>prefix-bits</b> ]  <b>add custom-ipv6 method</b> [ <b>manual</b> ] [ <b>ipv6-address</b> ] [ <b>prefix-bits</b> ]
<b>auto</b>	When this option is specified, the MCR-MGT Management Module will derive an IPv6 address from the entered network prefix and the MCR-MGT Management Module's MAC address. This is the default option.
<b>network-prefix</b>	Specify the IPv6 network prefix. The MCR-MGT Management Module will derive the complete IPv6 address from the entered network prefix and the MCR-MGT Management Module's MAC address.
<b>prefix-bits (auto)</b>	Specify the network prefix bits for the IPv6 address. <b>Range:</b> 0-64 <b>Default:</b> 64
<b>manual</b>	Specify this option when you want to enter a specific IPv6 address.
<b>ipv6-address</b>	Specify the complete IPv6 address. <b>Field Format:</b> IPv6 address
<b>prefix-bits (manual)</b>	Specify the network prefix bits for the IPv6 address. <b>Range:</b> 0-128 <b>Default:</b> 64

## Delete Custom-IPv6

<b>Description</b>	Deletes the specified custom IPv6 address. To see a list of configured IPv6 addresses, type the command <code>delete custom-ipv6 ?</code> .
<b>User Level</b>	Admin
<b>Syntax</b>	<code>delete custom-ipv6 &lt;config_ipv6_address&gt;</code>



# Chassis/slot Commands

---

## Chassis Commands

### Set Chassis Temperature-Threshold

<b>Description</b>	Sets the temperature threshold for the MCR1900 chassis.
<b>User Level</b>	Admin
<b>Syntax</b>	<b>set chassis temperature-threshold &lt;scale&gt; &lt;temperature&gt;</b>
<b>scale</b>	Specify whether the temperature will be specified in Celsius or Fahrenheit.
<b>temperature</b>	When the specified temperature is exceeded, alerts will be issued. Celsius 0-70 degrees Fahrenheit 32-158 degrees

### Set Chassis serial

<b>Description</b>	Sets the serial number for a SMI Media Converter.
<b>User Level</b>	Admin
<b>Syntax</b>	<b>set chassis serial &lt;text&gt;</b>
<b>text</b>	Sets the serial number for the SMI Media Converter. 16 characters

### Set Chassis management-module-slot

<b>Description</b>	Sets the management module's slot number for the SMI Media Converter.
<b>User Level</b>	Admin
<b>Syntax</b>	<b>set chassis management-module-slot &lt;1-2&gt;</b>
<b>1-2</b>	Specify whether the management module will be in slot 1 or slot 2.

## Set slot common parameters

<b>Description</b>	Sets generic parameters for a slot within the chassis. These apply regardless of the type of module which is inserted into the slot.
<b>User Level</b>	Admin
<b>Syntax</b>	<b>set slot &lt;slot #&gt; [auto-backup] [default-power]</b>
<b>slot #</b>	Specify the slot number. Valid options are 1-19.
<b>auto-backup</b>	This enables or disables the auto backup or restore of the configuration for the card which is inserted into this slot. When Specify the slot number. Valid options are 1-19.
<b>default-power</b>	This defines whether this slot will be powered up or not when the chassis is reset or powered up.

## Set slot, power schedule

<b>Description</b>	Configure a scheduled power on/off for a specific slot.
<b>User Level</b>	Admin
<b>Syntax</b>	<b>set slot &lt;slot #&gt; power-schedule entry [day] [on off] &lt;hh:mm&gt; [clear]</b>  <b>set slot &lt;slot #&gt; power-schedule mode &lt;enabled disabled&gt;</b>
<b>entry</b>	This command defines a new scheduled on or off time or clears an existing schedule.
<b>day</b>	This is the day of week on which to power the slot on or off.
<b>on off</b>	Defines if this is a power on or power off entry. <b>Values:</b> on or off
<b>&lt;hh:mm&gt; clear</b>	The time to power slot on or off. If "clear" is entered, it deletes an existing scheduled power on/off.
<b>mode</b>	This command defines is used to enable/disable the power schedule.

# Slot Control Commands

## Slot reset

<b>Description</b>	This command will reset the specified slot or the whole chassis. Specifying a * will reset the whole chassis.
<b>User Level</b>	Admin
<b>Syntax</b>	<code>slot &lt;slot #&gt; [reset][</code>
<b>slot #</b>	Specify a slot number <1-19>.
<b>reset</b>	<code>resets the module in that slot</code>

## Slot reset to factory

<b>Description</b>	This command will reset the configuration of the specified slot to factory default. Specifying a * will reset the whole chassis to factory default.
<b>User Level</b>	Admin
<b>Syntax</b>	<code>slot &lt;slot #&gt; [reset factory]</code>
<b>slot#</b>	Specify a slot number <1-19>
<b>factory</b>	<code>resets the module to factory defaults</code>

## Slot power

<b>Description</b>	This command will power a slot on or off.
<b>User Level</b>	Admin
<b>Syntax</b>	<code>slot &lt;slot #&gt; [power on off]</code>
<b>slot#</b>	1-19
<b>power</b>	<code>on off</code>

## Slot virtual-cable-test

<b>Description</b>	This command will initiate a virtual cable test on the copper port of the specified slot.
<b>User Level</b>	Admin
<b>Syntax</b>	<code>slot &lt;slot #&gt; [virtual-cable-test]</code>
<b>slot#</b>	1-19

## Slot loopback

<b>Description</b>	This command will initiate a fiber loopback on the fiber port of the specified slot.
<b>User Level</b>	Admin
<b>Syntax</b>	<code>slot &lt;slot #&gt; [loopback] [fiber-1 fiber-2 off] [1 2 off]</code>
<b>slot#</b>	1-19
<b>loopback#</b>	<code>fiber-1, fiber-2, 1, 2, on,off</code>

## Slot register read/write

<b>Description</b>	This command will enable the user to read or write any registers on the Media Converter Module. This should only be used when instructed to do so by a Perle Support Representative.
<b>User Level</b>	Admin
<b>Syntax</b>	<code>slot &lt;slot #&gt; phy read write address &lt;hex address&gt; register &lt;hex value&gt; [device &lt;hex value&gt;[page &lt;hex value&gt;]   [device assign clear-bits set-bits] &lt;hex value&gt;</code>

## Slot link-test

<b>Description</b>	<p>This command enables a port (on modules which support this feature) to perform link tests. These tests may be useful in identifying link issues.</p> <p><b>CM-10G modules</b></p> <p>The Link-Test on this module allows to generate patterns to be sent to the remote media converter. These tests can include packet sizes and data type to run.</p> <p><b>CM-10GT modules</b></p> <p>The Link Test ion this module involves sending a pattern to the remote peer, having him validate the pattern and send back a response indicating whether he received the pattern correctly or not. Based on the response from the peer, the local module is able to obtain one of three statuses for that transaction (which is repeated every second). See below for details.</p> <p><b><u>Link-Test Responses for CM-10GT</u></b></p> <p><b><u>Received</u></b></p> <ul style="list-style-type: none"> <li>● <b>Good</b> - The local module received a “good” response from the peer.</li> <li>● <b>Bad</b> - The response received from the peer was received in error or not received at all</li> </ul> <p><b><u>Transmitted:</u></b></p> <ul style="list-style-type: none"> <li>● <b>Good</b> - The remote peer indicated that the data sent by the local module was received correctly.</li> <li>● <b>Bad</b> - The remote peer indicated that the data sent by the local module was received in error</li> <li>● <b>Unknown</b> - The local module was unable to decode the message sent by the remote peer (this is a “bad” receive status). Since the local module is unable to decode what the peer sent back, it is unable to determine if the data it transmitted to the peer was received correctly.</li> </ul> <p><b>Note:</b> 1 gigabit modules do not support the link test when inserted in a 10GT module.</p>
<b>User Level</b>	Admin
<b>Syntax</b>	<pre>slot &lt;slot #&gt; link-test [1 2 off] [send-snmp-trap-on-error enabled   disabled] [packet-size &lt;256-8960&gt;]   [modes random sequential alternating] [alternating random   sequential] Default: 1500 bytes for 1 Gig modules Default: send-trap-on-error - Disabled</pre>

## Slot sfp/xfp (read memory)

<b>Description</b>	<p>This command enables a port on the 10G module to generate test patterns to a remote media converter module. If the remote media converter module is a Perle 10G then the remote end will automatically be put into loopback mode. This test is used to help identify link issues.</p>
<b>User Level</b>	Admin
<b>Syntax</b>	<p><b>For SFP modules without DMI support</b></p> <pre>slot &lt;slot #&gt; sfp [1 2] read a0 [start &lt;start addr 0-ff&gt;] [end &lt;end addr 0-ff&gt;]</pre> <p><b>For SFP modules with DMI support</b></p> <pre>slot &lt;slot #&gt; sfp [1 2] read [a0 a2][&lt;page 0-ff&gt;] [start &lt;start addr 0-ff&gt;] [end addr 0-ff&gt;]</pre> <p><b>For XFP modules with DMI support</b></p> <pre>slot &lt;slot #&gt; xfp [1 2] read [&lt;page 0-ff&gt;] [start &lt;start addr 0-ff&gt;] [end addr 0-ff&gt;]</pre>

# Slot Configuration Commands

## Set slot... cm-100

<b>Description</b>	Configure a cm-100 media converter module.
<b>User Level</b>	Admin
<b>Syntax</b>	<pre>set slot &lt;slot #&gt; cm-100 module [name &lt;text&gt;] [far-end-fault enabled disabled] [link-mode standard passthrough] set slot &lt;slot #&gt; cm-100 copper [port enabled disabled] [name &lt;text&gt;] [crossover auto mdi mdi-x] [auto-negotiation enabled disabled] [pause enabled disabled] set slot &lt;slot #&gt; cm-100 fiber [port enabled disabled] [name &lt;text&gt;]</pre>
<b>module</b>	This command defines parameters which apply to the whole media converter module.
<b>name</b>	The name to be associated with this module. Values: 0-63 characters
<b>far-end-fault</b>	When enabled, if the Media Converter Module detects a loss of signal on the fiber receiver, it will transmit a FEF signal to the remote Media Converter Module. This, in effect, notifies the fiber link partner that an error condition exists on the fiber connection. <b>Note:</b> This feature only takes effect if Auto Negotiation has been turned off. When disabled, the Media Converter Module will not monitor for or generate Far End Fault.
<b>link-mode</b>	<b>Standard:</b> In this mode, the links on the fiber and copper sides can be brought up and down independently of each other. A loss of link on either the fiber or copper port can occur without affecting the other connection. <b>Smart Link Pass-Through:</b> In this mode, the link state on one connection is directly reflected through the Media Converter Module to the other connection. If link is lost on one of the connections, then the other link will be brought down by the Media Converter. <b>Default:</b> Passthrough
<b>copper</b>	This command defines parameters which apply to the copper port of the media converter module.
<b>port</b>	Enable or disable this port.
<b>name</b>	The name to be associated with this port. 1-8 characters
<b>auto-negotiation</b>	When enabled, the Media Converter Module will negotiate with its link partner to determine the most optimal parameters for this connection.
<b>crossover</b>	<ul style="list-style-type: none"> <li>● <b>Auto-Detect</b>— automatically detects the Ethernet's cable polarity</li> <li>● <b>MDI</b> —the cable's polarity is straight-through</li> <li>● <b>MDI-X</b> —the cable's polarity is crosscovered</li> </ul> <b>Default:</b> Auto
<b>pause</b>	<ul style="list-style-type: none"> <li>●</li> </ul> When enabled, the Media Converter Module will advertise its Pause capabilities.

<b>fiber</b>	This command defines parameters which apply to the fiber port of the media converter module.
<b>port name</b>	Enable or disable this port. The name to be associated with this port. 1-8 characters

## Set slot... cm-100mm

<b>Description</b>	Configure a cm-100mm media converter module.
<b>User Level</b>	Admin
<b>Syntax</b>	<pre>set slot &lt;slot #&gt; cm-100mm module [name &lt;text&gt;] [link-mode standard passthrough] [far-end-fault disabled enabled] set slot &lt;slot #&gt; cm-100mm fiber[1 2] [name &lt;text&gt;] [port enabled disabled]</pre>
<b>module name</b>	This command defines parameters which apply to the whole media converter module. The name to be associated with this module. 0-63 characters
<b>link-mode</b>	<b>Smart Link Pass-Through:</b> In this mode, the link state on one fiber connection is directly reflected through the Media Converter Module to the other fiber connection. If link is lost on one of the fiber connections, then the other fiber link will be brought down by the Media Converter. <b>Standard:</b> In this mode, each fiber link can be brought up and down independently of each other. A loss of signal on either fiber connection can occur without affecting the other fiber connection. <b>Default:</b> Smart Link Pass-Through
<b>far-end-fault</b>	When enabled, if the media converter module detects a loss of signal on the fiber receiver, it will immediately send an FEF on the transmitter of its fiber link to the remote end module. This, in effect, notifies the fiber link partner that an error condition exists on the fiber link. connection. <b>Note:</b> This feature only takes effect if Auto Negotiation has been turned off. When disabled, the media converter module will not monitor for or generate Far End Fault. <b>Default:</b> On
<b>name</b>	The name to be associated with this port. 1-8 characters
<b>fiber</b>	This command defines parameters which apply to the fiber port of the media converter module.
<b>port name</b>	Enable or disable this port. The name to be associated with this port.

## Set slot... cm-1000

<b>Description</b>	Configure a cm-1000 media converter module.
<b>User Level</b>	Admin

<b>Syntax</b>	<pre> set slot &lt;slot #&gt; cm-1000 module {auto-negotiation enabled disabled} [name &lt;text&gt;] [fiber-fault-alert enabled disabled]] [jumbo-packets enabled disabled] [link-mode standard smart-link-passthrough] set slot &lt;slot #&gt; cm-1000 copper [port] [name &lt;text&gt;] [duplex half auto] [low-power-mode enabled disabled] [pause disabled symmetrical asymmetrical-tx asymmetrical-rx] set slot &lt;slot #&gt; cm-1000 fiber [port] [name] [auto-negotiation] </pre>
<b>module</b>	This command defines parameters which apply to the whole media converter module.
<b>auto-negotiation</b>	<p><b>Enabled:</b> The Media Converter Module will negotiate Ethernet parameters on the fiber connection. This will ensure that the most optimal connection parameters will be in effect.</p> <p><b>Disabled:</b> The Media Converter Module will negotiate the Ethernet parameter's with the copper link partner. The parameters used will be determined by the Duplex and Pause settings.</p>
<b>name</b>	<p>The name to be associated with this module.</p> <p>0-63 characters</p>
<b>fiber-fault-alert</b>	<p>When enabled, if the Media Converter Module detects a loss of signal on the fiber receiver, it will immediately disable its fiber transmitter signal on this port. This in effect, notifies the fiber link partner that an error condition exists on the fiber connection.</p> <p><b>Note:</b> This feature only takes effect if Fiber Negotiation has been turned off. When disabled, the Media Converter Module will not monitor for or generate Fiber Fault.</p>
<b>jumbo-packets</b>	<p>Enable Jumbo Packet support.</p> <p><b>Default:</b> Enabled</p>
<b>link-mode</b>	<p><b>Standard:</b> In this mode, the links on the fiber and copper sides can be brought up and down independently of each other. A loss of link on either the fiber or copper port can occur without affecting the other connection.</p> <p><b>Smart Link Pass-Through:</b> In this mode, the link state on one connection is directly reflected through the Media Converter Module to the other connection. If link is lost on one of the connections, then the other link will be brought down by the Media Converter.</p> <p><b>Default:</b> Passthrough</p>
<b>copper</b>	This command defines parameters which apply to the copper port of the media converter module.
<b>port</b>	Enable or disable this port.
<b>name</b>	<p>The name to be associated with this port.</p> <p>1-8 characters</p>
<b>duplex</b>	<p>The following selections are available:</p> <p><b>Duplex:</b> Auto, Half</p> <p><b>Default:</b> Auto</p>
<b>low-power-mode</b>	If enabled, the Gigabit copper transceiver is set into low power mode which reduces the strength of the copper signal.

<b>pause</b>	<p>When enabled, the Media Converter Module will advertise the following Pause capabilities:</p> <ul style="list-style-type: none"> <li>● Disabled</li> <li>● Symmetrical</li> <li>● Asymmetrical TX</li> <li>● Asymmetrical RX</li> </ul> <p><b>Note: Pause feature will only work if Auto Negotiation is set to OFF on the fiber port and Duplex is set to Full.</b></p>
<b>fiber</b>	This command defines parameters which apply to the fiber port of the media converter module.
<b>port</b>	Enable or disable this port.
<b>name</b>	<p>The name to be associated with this port.</p> <p>1-8 characters</p>

## Set slot... cm-1000mm

<b>Description</b>	Configure a cm-1000mm media converter module.
<b>User Level</b>	Admin
<b>Syntax</b>	<pre>set slot &lt;slot #&gt; cm-1000mm module [auto-negotiation enabled disabled] [name &lt;text&gt;] [fiber-fault-alert enabled disabled]] [jumbo-packets enabled disabled] [link-mode standard smart-link-passthrough] set slot &lt;slot #&gt; cm-1000mm fiber [port enabled disabled] [name &lt;text&gt;]</pre>
<b>module</b>	This command defines parameters which apply to the whole media converter module.
<b>auto-negotiation</b>	<p><b>Enabled:</b> The Media Converter Module will negotiate Ethernet parameters on the fiber connection. This will ensure that the most optimal connection parameters will be in effect.</p> <p><b>Disabled:</b> The Media Converter Module will negotiate the Ethernet parameter's with the copper link partner. The parameters used will be determined by the Duplex and Pause settings.</p>
<b>name</b>	<p>The name to be associated with this module.</p> <p>0-63 characters</p>
<b>fiber-fault-alert</b>	<p>When enabled, if the Media Converter Module detects a loss of signal on the fiber receiver, it will immediately disable its fiber transmitter signal on this port. This in effect, notifies the fiber link partner that an error condition exists on the fiber connection.</p> <p><b>Note:</b> This feature only takes effect if Fiber Negotiation has been turned off.</p> <p>When disabled, the Media Converter Module will not monitor for or generate Fiber Fault.</p>
<b>jumbo-packets</b>	<p>Enable Jumbo Packet support.</p> <p><b>Default:</b> Enabled</p>

<b>link-mode</b>	<p><b>Smart Link Pass-Through:</b> In this mode, the link state on one fiber connection is directly reflected through the Media Converter Module to the other fiber connection. If link is lost on one of the fiber connections, then the other fiber link will be brought down by the Media Converter.</p> <p><b>Standard:</b> In this mode, each fiber link can be brought up and down independently of each other. A loss of signal on either fiber connection can occur without affecting the other fiber connection.</p> <p><b>Default:</b> Smart Link Pass-Through</p>
<b>fiber</b>	This command defines parameters which apply to the fiber port of the media converter module.
<b>port</b>	Enable or disable this port.
<b>name</b>	The name to be associated with this port. 1-8 characters

## Set slot... cm-110

<b>Description</b>	Configure a cm-110 media converter module.
<b>User Level</b>	Admin
<b>Syntax</b>	<pre>set slot &lt;slot #&gt; cm-110 module [name &lt;text&gt;] [far-end-fault enabled disabled] [link-mode standard passthrough] [max-packet-size 1522 2048] [map-priority-to-egress-queue &lt;0-7&gt; &lt;0-3&gt;] [unidirectional-ethernet disabled copper-to-fiber fiber-to-copper]  set slot &lt;slot #&gt; cm-110 copper [port enabled disabled] [name &lt;text&gt;] [crossover auto mdi mdi-x] [auto-negotiation enabled disabled] [pause enabled disabled] [10baset-distance normal extended] [8021p-priority enabled disabled] [ip-tos-priority enabled disabled] [priority-precedence 8021p ip-tos] [congestion-policy strict-queueing weighted-queueing] [remap- priority &lt;0-7&gt; &lt;0-7&gt;] [ingress-rate-limit none 64kbps 128kbps  192kbps 256kbps 320kbps 384kbps 512kbps 768kbps 1mbps 2mbps  3mbps 4mbps 5mbps 6mbps 7mbps 8mbps 9mbps 10mbps 20mbps 30mbps  40mbps 50mbps 60mbps 70mbps 80mbps 90mbps] [egress-rate-limit none 64kbps 128kbps 192kbps 256kbps 320kbps 384kbps 512kbps 768k bps 1mbps 2mbps 3mbps 4mbps 5mbps 6mbps 7mbps 8mbps 9mbps 10mbps  20mbps 30mbps 40mbps 50mbps 60mbps 70mbps 80mbps 90mbps] [default-priority &lt;0-7&gt;] [default-vlan-id &lt;0-4095&gt;] [discard-tagged-frames enabled disabled] [discard-untagged-frames enabled disabled] [vlan-tagging-action none untag tag double-tag] [filter-unknown-multicast enabled disabled] [filter-unknown-unicast enabled disabled]</pre>

	<pre> set slot &lt;slot #&gt; cm-110 fiber [port enabled disabled] [name &lt;text&gt;] [duplex full half] [8021p-priority enabled disabled] [&lt;tos-priority enabled disabled&gt;] [priority-precedence 8021p ip-tos] [congestion-policy strict-queueing weighted-queueing] [remap- priority &lt;0-7&gt; &lt;0-7&gt;] [ingress-rate-limit none 64kbps 128kbps  192kbps 256kbps 320kbps 384kbps 512kbps 768kbps 1mbps 2mbps  3mbps 4mbps 5mbps 6mbps 7mbps 8mbps 9mbps 10mbps 20mbps 30mbps  40mbps 50mbps 60mbps 70mbps 80mbps 90mbps] [egress-rate-limit none 64kbps 128kbps 192kbps 256kbps 320kbps 384kbps 512kbps 768k bps 1mbps 2mbps 3mbps 4mbps 5mbps 6mbps 7mbps 8mbps 9mbps 10mbps  20mbps 30mbps 40mbps 50mbps 60mbps 70mbps 80mbps 90mbps] [default-priority &lt;0-7&gt;] [default-vlan-id &lt;0-4095&gt;] [discard-tagged-frames enabled disabled] [discard-untagged-frames enabled disabled] [vlan-tagging-action none untag tag double-tag] [filter-unknown-multicast enabled disabled] [filter-unknown-unicast enabled disabled] </pre>
<b>module</b>	This command defines parameters which apply to the whole media converter module.
<b>name</b>	The name to be associated with this module.
<b>far-end-fault</b>	<p>When enabled, if the Media Converter Module detects a loss of signal on the fiber receiver, it will transmit a FEF signal to the remote Media Converter Module. This, in effect, notifies the fiber link partner that an error condition exists on the fiber connection.</p> <p><b>Note:</b> This feature only takes effect if Auto Negotiation has been turned off. When disabled, the Media Converter Module will not monitor for or generate Far End Fault.</p>
<b>link-mode</b>	<p><b>Standard:</b> In this mode, the links on the fiber and copper sides can be brought up and down independently of each other. A loss of link on either the fiber or copper port can occur without affecting the other connection.</p> <p><b>Smart Link Pass-Through:</b> In this mode, the link state on one connection is directly reflected through the Media Converter Module to the other connection. If link is lost on one of the connections, then the other link will be brought down by the Media Converter.</p> <p><b>Default:</b> Passthrough</p>
<b>max-packet-size</b>	<p><b>Select the maximum packet size.</b></p> <p><b>Options:</b> 1522 bytes or 2048 bytes</p> <p><b>Default:</b> 2048</p>
<b>unidirectional-ethernet</b>	<p>When enabled, this feature provides the ability to restrict the port to one-way traffic flow.</p> <p><b>Values:</b></p> <ul style="list-style-type: none"> <li>● Disabled</li> <li>● Copper to Fiber</li> <li>● Fiber to Copper</li> </ul> <p><b>Default:</b> Disabled</p>
<b>copper</b>	This command defines parameters which apply to the copper port of the media converter module.
<b>port</b>	Enable or disable this port.

<b>name</b>	The name to be associated with this port. 1-8 characters
<b>auto-negotiation</b>	When enabled, the Media Converter Module will negotiate with its link partner to determine the most optimal parameters for this connection.
<b>crossover</b>	<ul style="list-style-type: none"> <li>● <b>Auto-Detect</b>— automatically detects the Ethernet’s cable polarity</li> <li>● <b>MDI</b> —the cable’s polarity is straight-through</li> <li>● <b>MDI-X</b> —the cable’s polarity is crossovered</li> </ul> <b>Default:</b> Auto
<b>pause</b>	When enabled, the Media Converter Module will advertise its Pause capabilities.
<b>10baset-distance</b>	<b>Normal:</b> the Media Converter copper link is in normal operating mode. <b>Extended:</b> the Media Converter will boost the signal strength on its copper link.
<b>802.1p- priority</b>	When enabled, the media converter module will use IEEE 802.1p tagged frame priority control to assign ingress frames to the appropriate priority egress queue. <b>Default:</b> Enabled
<b>ip-tos- priority</b>	When enabled, the media converter module will use IPv4 Diffserv or IPv6 traffic class field to assign ingress frames to the appropriate priority egress queue. <b>Default:</b> Enabled
<b>priority- precedence</b>	When both 802.1p priority and TOS priority are selected, you can select which of the two priorities takes precedence. <b>Default:</b> 802.1p
<b>congestion policy</b>	Select a method to be used when determining the order by which frames are sent from the four egress queues. Setting the congestion policy on either the fiber or copper port will change the policy on both ports. <b>Strict Priority Queuing</b> - The order is determined strictly by the priority of the queue. Frames in higher priority queues are always sent ahead of frames in lower priority queues. <b>Weighted Fair Queuing</b> - This method allows lower priority frames to be intermixed with higher priority frames in the ratio of <b>(8, 4, 2, 1)</b> . The ratio for 8 highest priority sent frames will be as follows: <b>8</b> highest priority frames from queue 3 <b>4</b> frames from queue 2 <b>2</b> frames from queue 1 <b>1</b> frame from queue 0 <b>Default:</b> Strict Priority Queuing
<b>remap-priority</b>	Remap IEEE 802.1p ingress frames with a new priority tag. This new priority tag will be used to determine which queue the frame gets posted to.  <b>Original Priority -----&gt; New Priority</b>  <b>Values:</b> 0-7
<b>ingress-rate</b>	Restricts ingress frames on the copper port. <b>Default:</b> None <b>Data Options:</b> 64 kbps to 90 Mbps
<b>egress-rate</b>	Restricts egress frames on the copper port. <b>Default:</b> None <b>Data Options:</b> 64 kbps to 90 Mbps

<b>discard-tagged frames</b>	When enabled, discards all VLAN tagged frames. <b>Default:</b> Off
<b>discard-untagged frames</b>	When enabled, discards all VLAN untagged frames. <b>Default:</b> Off
<b>default-vlan-id</b>	Specify a default VLAN ID to insert when tagging frames. <b>Default:</b> 1 <b>Data Options:</b> 0-4095
<b>default-priority</b>	Specify a default VLAN priority to insert when tagging frames. <b>Default:</b> 0 <b>Data Options:</b> 0-7
<b>vlan-tagging actions</b>	Define the VLAN tagging action to take on a egress frame. <ul style="list-style-type: none"> <li>● Normal -Take no action.</li> <li>● Untag - Remove any existing tag.</li> <li>● Tag <ul style="list-style-type: none"> <li>Insert tag with configured VLAN ID and VLAN priority if original frame is untagged.</li> <li>Replace tag with configured VLAN ID and VLAN priority if original frame is tagged.</li> </ul> </li> <li>● Double tag - Append a tag with configured VLAN ID and VLAN priority.</li> </ul> <b>Default:</b> Normal
<b>fiber</b>	This command defines parameters which apply to the fiber port of the media converter module.
<b>port</b>	Enable or disable this port.
<b>name</b>	The name to be associated with this port. 1-8 characters
<b>duplex</b>	The following selections are available: <b>Duplex:</b> Full, Half <b>Default:</b> Full
<b>8021p- priority</b>	When enabled, the media converter module will use IEEE 802.1p tagged frame priority control to assign ingress frames to the appropriate priority egress queue. <b>Default:</b> Enabled
<b>ip-tos</b>	When enabled, the media converter module will use IPv4 Diffserv or IPv6 traffic class field to assign ingress frames to the appropriate priority egress queue. <b>Default:</b> Enabled
<b>priority-precedence</b>	When both 802.1p priority and TOS priority are selected, you can select which of the two priorities takes precedence. <b>Default:</b> 802.1p

<b>congestion-policy</b>	<p>Select a method to be used when determining the order by which frames are sent from the four egress queues. Setting the congestion policy on either the fiber or copper port will change the policy on both ports.</p> <p><b>Strict Priority Queuing</b> - The order is determined strictly by the priority of the queue. Frames in higher priority queues are always sent ahead of frames in lower priority queues.</p> <p><b>Weighted Fair Queuing</b> - This method allows lower priority frames to be intermixed with higher priority frames in the ratio of <b>(8, 4, 2, 1)</b>.</p> <p>The ratio for 8 highest priority sent frames will be as follows:</p> <ul style="list-style-type: none"> <li><b>8</b> highest priority frames from queue 3</li> <li><b>4</b> frames from queue 2</li> <li><b>2</b> frames from queue 1</li> <li><b>1</b> frame from queue 0</li> </ul> <p><b>Default:</b> Strict Priority Queuing</p>
<b>remap-priority</b>	<p>Remap IEEE 802.1p ingress frames with a new priority tag. This new priority tag will be used to determine which queue the frame gets posted to.</p> <p><b>Original Priority -----&gt; New Priority</b></p> <p><b>Values:</b> 0-7</p>
<b>ingress-rate</b>	<p>Restricts ingress frames on the fiber port.</p> <p><b>Default:</b> None</p> <p><b>Data Options:</b> 64 kbps to 90 Mbps</p>
<b>egress-rate</b>	<p>Restricts egress frames on the fiber port.</p> <p><b>Default:</b> None</p> <p><b>Data Options:</b> 64 kbps to 90 Mbps</p>
<b>filter-unknown-multicast</b>	<p>When enabled, multicast frames with unknown destination addresses are not allowed to egress this port.</p> <p><b>Default:</b> Disabled</p>
<b>filter-unknown-unicast</b>	<p>When enabled, unicast frames with unknown destination addresses are not allowed to egress this port.</p> <p><b>Default:</b> Disabled</p>
<b>default-vlan-id</b>	<p>Specify a default VLAN ID to insert when tagging frames.</p> <p><b>Default:</b> 1</p> <p><b>Data Options:</b> 0-4095</p>
<b>default -priority</b>	<p>Specify a default VLAN priority to insert when tagging frames.</p> <p><b>Default:</b> 0</p> <p><b>Data Options:</b> 0-7</p>
<b>vlan-tagging-action</b>	<p>Define the VLAN tagging action to take on a egress frame.</p> <ul style="list-style-type: none"> <li>● Normal -Take no action.</li> <li>● Untag - Remove any existing tag.</li> <li>● Tag <ul style="list-style-type: none"> <li>Insert tag with configured VLAN ID and VLAN priority if original frame is untagged.</li> <li>Replace tag with configured VLAN ID and VLAN priority if original frame is tagged.</li> </ul> </li> <li>● Double tag - Append a tag with configured VLAN ID and VLAN priority.</li> </ul> <p><b>Default:</b> Normal</p>

## Set slot... cm-1110

<b>Description</b>	Configure a cm-1110 media converter module.
<b>User Level</b>	Admin
<b>Syntax</b>	<pre> set slot &lt;slot #&gt; cm-1110 module [name &lt;text&gt;] [fiber-fault-alert enabled disabled] [link-mode standard smart-link-passthrough] [max-packet-size 1522 2048 10240] [map-priority-to-egress-queue &lt;0-7&gt; &lt;0-3&gt;] [unidirectional-ethernet disabled copper-to-fiber fiber-to-copper] set slot &lt;slot #&gt; cm-1110 copper [port enabled disabled] [name &lt;text&gt;] [crossover auto mdi mdi-x] [auto-negotiation enabled disabled] [pause disabled symmetrical asymmetrical-tx asymmetrical-rx] [10baset-distance normal extended] [downshift &lt;0-8&gt;] [8021p-priority enabled disabled tos-priority enabled disabled] [priority-precedence 8021p ip-tos] congestion-policy [strict-queueing weighted-queueing] [remap- priority &lt;0-7&gt; &lt;0-7&gt; [ingress-rate-limit none 64kbps 128kbps  192kbps 256kbps 320kbps 384kbps 512kbps 768kbps 1mbps 2mbps  3mbps 4mbps 5mbps 6mbps 7mbps 8mbps 9mbps 10mbps 20mbps 30mbps  40mbps 50mbps 60mbps 70mbps 80mbps 90mbps] [egress-rate-limit none 64kbps 128kbps 192kbps 256kbps 320kbps 384kbps 512kbps 768k bps 1mbps 2mbps 3mbps 4mbps 5mbps 6mbps 7mbps 8mbps 9mbps 10mbps  20mbps 30mbps 40mbps 50mbps 60mbps 70mbps 80mbps 90mbps 100mbps  200mbps 300mbps 400mbps 500mbps 600mbps 700mbps 800mbps 900mbps ] [default-priority &lt;0-7&gt;] [default-vlan-id &lt;0-4095&gt;] [discard-tagged-frames enabled disabled] [discard-untagged-frames enabled disabled] [vlan-tagging-action none untag tag double-tag] [filter-unknown-multicast enabled disabled] [filter-unknown-unicastmulticast enabled disabled] set slot &lt;slot #&gt; cm-1110 fiber [port enabled disabled] [name &lt;text&gt;] [auto-negotiation enabled disabled] [8021p-priority enabled disabled] [ip-tos-priority enabled disabled] [priority-precedence 8021p ip-tos] congestion-policy [strict-queueing weighted-queueing] [remap- priority &lt;0-7&gt; &lt;0-7&gt; [ingress-rate-limit none 64kbps 128kbps  192kbps 256kbps 320kbps 384kbps 512kbps 768kbps 1mbps 2mbps  3mbps 4mbps 5mbps 6mbps 7mbps 8mbps 9mbps 10mbps 20mbps 30mbps  40mbps 50mbps 60mbps 70mbps 80mbps 90mbps] [egress-rate-limit none 64kbps 128kbps 192kbps 256kbps 320kbps 384kbps 512kbps 768k bps 1mbps 2mbps 3mbps 4mbps 5mbps 6mbps 7mbps 8mbps 9mbps 10mbps  20mbps 30mbps 40mbps 50mbps 60mbps 70mbps 80mbps 90mbps 100mbps  200mbps 300mbps 400mbps 500mbps 600mbps 700mbps 800mbps 900mbps ] [default-priority &lt;0-7&gt;] [default-vlan-id &lt;0-4095&gt;] [discard-tagged-frames enabled disabled] [discard-untagged-frames enabled disabled] [sgmii-interface enable disable] [vlan-tagging-action none untag tag double-tag] [filter-unknown-multicast enabled disabled] [filter-unknown-unicastmulticast enabled disabled] </pre>
<b>module</b>	This command defines parameters which apply to the whole media converter module.
<b>name</b>	The name to be associated with this module. 0-63 characters

<b>fiber-fault-alert</b>	<p>When enabled, if the Media Converter Module detects a loss of signal on the fiber receiver, it will immediately disable its fiber transmitter signal on this port. This in effect, notifies the fiber link partner that an error condition exists on the fiber connection.</p> <p><b>Note:</b> This feature only takes effect if Fiber Negotiation has been turned off. When disabled, the Media Converter Module will not monitor for or generate Fiber Fault.</p>
<b>link-mode</b>	<p><b>Standard:</b> In this mode, the links on the fiber and copper sides can be brought up and down independently of each other. A loss of link on either the fiber or copper port can occur without affecting the other connection.</p> <p><b>Smart Link Pass-Through:</b> In this mode, the link state on one connection is directly reflected through the Media Converter Module to the other connection. If link is lost on one of the connections, then the other link will be brought down by the Media Converter.</p> <p><b>Default:</b> Passthrough</p>
<b>max-packet-size</b>	<p><b>Select the maximum packet size.</b></p> <p><b>Options:</b> 1522, 2048, 10240</p> <p><b>Default:</b> 1522</p>
<b>Unidirectional Ethernet</b>	<p>When enabled, this feature provides the ability to restrict the port to one-way traffic flow.</p> <p><b>Values:</b></p> <ul style="list-style-type: none"> <li>● Disabled</li> <li>● Copper to Fiber</li> <li>● Fiber to Copper</li> </ul> <p><b>Default:</b> Disabled</p>
<b>Map Priority to Egress Queue</b>	<p>This is the <b>default</b> egress priority mapping for both the copper and fiber ports.</p> <p>Priority 0 (lowest priority)..Queue 0  Priority 1.....Queue 0  Priority 2.....Queue 1  Priority 3.....Queue 1  Priority 4.....Queue 2  Priority 5.....Queue 2  Priority 6.....Queue 3  Priority 7 (highest priority)..Queue 3</p>
<b>copper</b>	<p>This command defines parameters which apply to the copper port of the media converter module.</p>
<b>port</b>	<p>Enable or disable this port.</p>
<b>name</b>	<p>The name to be associated with this port.</p>
<b>crossover</b>	<ul style="list-style-type: none"> <li>● <b>Auto-Detect</b>— automatically detects the Ethernet’s cable polarity</li> <li>● <b>MDI</b>—the cable’s polarity is straight-through</li> <li>● <b>MDI-X</b>—the cable’s polarity is crosscovered</li> </ul> <p><b>Default:</b> Auto</p>

<b>auto-negotiation</b>	When enabled, the Media Converter Module will negotiate with its link partner to determine the most optimal parameters for this connection.
<b>pause</b>	<p>pause</p> <p>When enabled, the Media Converter Module will advertise the following Pause capabilities:</p> <ul style="list-style-type: none"> <li>● Disabled</li> <li>● Symmetrical</li> <li>● Asymmetrical TX</li> <li>● Asymmetrical RX</li> </ul> <p><b>Note: Pause feature will only work if Auto Negotiation is set to OFF on the fiber port and Duplex is set to Full.</b></p>
<b>10baset-distance</b>	<p><b>Normal:</b> the Media Converter copper link is in normal operating mode.</p> <p><b>Extended:</b> the Media Converter will boost the signal strength on its copper link.</p>
<b>downshift</b>	<p>When enabled, the number of retries the Media Converter Module will attempt to establish a fiber connection at 1000 Mbps before attempting a lower speed.</p> <p><b>Default:</b> Off</p>
<b>8021p- priority</b>	<p>When enabled, the media converter module will use IEEE 802.1p tagged frame priority control to assign ingress frames to the appropriate priority egress queue.</p> <p><b>Default:</b> Enabled</p>
<b>ip-tos-priority</b>	<p>When enabled, the media converter module will use IPv4 Diffserv or IPv6 traffic class field to assign ingress frames to the appropriate priority egress queue.</p> <p><b>Default:</b> Enabled</p>
<b>priority- precedence</b>	<p>When both 802.1p priority and TOS priority are selected, you can select which of the two priorities takes precedence.</p> <p><b>Default:</b> 802.1p</p>
<b>congestion-policy</b>	<p>Select a method to be used when determining the order by which frames are sent from the four egress queues.</p> <p><b>Strict Priority Queuing</b> - The order is determined strictly by the priority of the queue. Frames in higher priority queues are always sent ahead of frames in lower priority queues.</p> <p><b>Weighted Fair Queuing</b> - This method allows lower priority frames to be intermixed with higher priority frames in the ratio of <b>(8, 4, 2, 1)</b>.</p> <p>The ratio for 8 highest priority sent frames will be as follows:</p> <p><b>8</b> highest priority frames from queue 3</p> <p><b>4</b> frames from queue 2</p> <p><b>2</b> frames from queue 1</p> <p><b>1</b> frame from queue 0</p>
<b>remap-priority</b>	<p>Remap IEEE 802.1p ingress frames with a new priority tag. This new priority tag will be used to determine which queue the frame gets posted to.</p> <p><b>Original Priority -----&gt; New Priority</b></p> <p><b>Values:</b> 0-7</p>

<b>ingress-rate</b>	Restricts ingress frames on the copper port. <b>Default:</b> None <b>Data Options:</b> 64 kbps to 900 mbps
<b>egress-rate</b>	Restricts egress frames on the copper port. <b>Default:</b> None <b>Data Options:</b> 64kbps to 900 mbps
<b>discard-tagged-frames</b>	When enabled, discards all VLAN tagged frames. <b>Default:</b> Off
<b>discard-untagged-frames</b>	When enabled, discards all VLAN untagged frames. <b>Default:</b> Off
<b>sgmii-interface</b>	Enable sgmii interface if your SFP supports this interface.
<b>default-vlan-id</b>	Specify a default VLAN ID to insert when tagging frames. <b>Default:</b> 1 <b>Data Options:</b> 0-4095
<b>default-priority</b>	Specify a default VLAN priority to insert when tagging frames. <b>Default:</b> 0 <b>Data Options:</b> 0-7
<b>vlan-tagging-action</b>	Define the VLAN tagging action to take on a egress frame. <ul style="list-style-type: none"> <li>● Normal -Take no action.</li> <li>● Untag - Remove any existing tag.</li> <li>● Tag <ul style="list-style-type: none"> <li>Insert tag with configured VLAN ID and VLAN priority if original frame is untagged.</li> <li>Replace tag with configured VLAN ID and VLAN priority if original frame is tagged.</li> </ul> </li> <li>● Double tag - Append a tag with configured VLAN ID and VLAN priority.</li> </ul> <b>Default:</b> Normal
<b>fiber</b>	This command defines parameters which apply to the fiber port of the media converter module.
<b>port</b>	Enable or disable this port.
<b>name</b>	The name to be associated with this port. 1-8 characters
<b>auto-negotiation</b>	<b>Enabled:</b> The Media Converter Module will negotiate Ethernet parameters on the fiber connection. This will ensure that the most optimal connection parameters will be in effect. <b>Disabled:</b> The Media Converter Module will negotiate the Ethernet parameter's with the copper link partner. The parameters used will be determined by the Duplex and Pause settings.
<b>802.1p-priority</b>	When enabled, the media converter module will use IEEE 802.1p tagged frame priority control to assign ingress frames to the appropriate priority egress queue. <b>Default:</b> Enabled
<b>ip-tos-priority</b>	When enabled, the media converter module will use IPv4 Diffserv or IPv6 traffic class field to assign ingress frames to the appropriate priority egress queue. <b>Default:</b> Enabled

<b>priority- precedence</b>	When both 802.1p priority and TOS priority are selected, you can select which of the two priorities takes precedence. <b>Default:</b> 802.1p
<b>congestion-policy</b>	Select a method to be used when determining the order by which frames are sent from the four egress queues. <b>Strict Priority Queuing</b> - The order is determined strictly by the priority of the queue. Frames in higher priority queues are always sent ahead of frames in lower priority queues. <b>Weighted Fair Queuing</b> - This method allows lower priority frames to be intermixed with higher priority frames in the ratio of <b>(8, 4, 2, 1)</b> . The ratio for 8 highest priority sent frames will be as follows: <b>8</b> highest priority frames from queue 3 <b>4</b> frames from queue 2 <b>2</b> frames from queue 1 <b>1</b> frame from queue 0
<b>remap-priority</b>	Remap IEEE 802.1p ingress frames with a new priority tag. This new priority tag will be used to determine which queue the frame gets posted to.  <b>Original Priority -----&gt; New Priority</b>  <b>Values:</b> 0-7
<b>ingress-rate</b>	Restricts ingress frames on the fiber port. <b>Default:</b> None <b>Data Options:</b> 64 kbps to 900 mbps
<b>egress-rate</b>	Restricts egress frames on the fiber port. <b>Default:</b> None <b>Data Options:</b> 64 kbps to 900 mbps
<b>filter-unknown- multicast</b>	When enabled, multicast frames with unknown destination addresses are not allowed to egress this port. <b>Default:</b> Disabled
<b>filter-unknown- unicast</b>	When enabled, unicast frames with unknown destination addresses are not allowed to egress this port. <b>Default:</b> Disabled
<b>default-vlan-id</b>	Specify a default VLAN ID to insert when tagging frames. <b>Default:</b> 1 <b>Data Options:</b> 0-4095
<b>default-priority</b>	Specify a default VLAN priority to insert when tagging frames. <b>Default:</b> 0 <b>Data Options:</b> 0-7

**vlan-tagging-actions**

Define the VLAN tagging action to take on a egress frame.

- Normal - Take no action.
- Untag - Remove any existing tag.
- Tag
  - Insert tag with configured VLAN ID and VLAN priority if original frame is untagged.
  - Replace tag with configured VLAN ID and VLAN priority if original frame is tagged.
- Double tag - Append a tag with configured VLAN ID and VLAN priority.

**Default:** Normal

**Set slot... cm-10g**
**Description**  
**User Level**  
**Syntax**

Configure a cm-10g media converter module.  
Admin

For STS modules only

```
set slot <slot#> cm-10g [fiber-auto-negotiation enabled|disabled]
```

\*For SFP ports

```
set slot <slot#> cm-10g module [fiber-fault-alert
disabled|enabled] [link-mode standard|smart-link-passthrough]
[name <name>]
```

```
set slot <slot#> cm-10g [port 1|2] [edc-mode
auto|linear|limiting|cx1] [frequency-control
enable|disable] [channel <1-65535>] [name <text>] [port
enabled|disabled] [tx-dither-control enable|disabled]
[wave-length-control enable|disable] [wavelength <0-65535>]
```

\* Note: See manufacturers documentation for parameter settings.

\*For XFP ports

```
set slot <slot#> cm-10g [port 1|2] [fec
enabled|disabled] [amplitude-adjustment <-128 -
127>] [phase-adjustment <-128 - 127>] [frequency-control
enable|disable] [channel <1-65535>] [name <text>] [port
enabled|disabled] [tx-dither-control enable|disabled]
[wave-length-control enable|disable] [wavelength <0-65535>]
```

\* Note: See manufacturers documentation for parameter settings.

**fiber-fault-alert**

When enabled, if the Media Converter Module detects a loss of signal on the fiber receiver, it will immediately disable its fiber transmitter signal on this port. This in effect, notifies the fiber link partner that an error condition exists on the fiber connection.

**Note:** This feature only takes effect if Fiber Negotiation has been turned off.

When disabled, the Media Converter Module will not monitor for or generate Fiber Fault.

<b>link-mode</b>	<p><b>Smart Link Pass-Through:</b> In this mode, the link state on one fiber connection is directly reflected through the Media Converter Module to the other fiber connection. If link is lost on one of the fiber connections, then the other fiber link will be brought down by the Media Converter.</p> <p><b>Standard:</b> In this mode, each fiber link can be brought up and down independently of each other. A loss of signal on either fiber connection can occur without affecting the other fiber connection.</p> <p><b>Default:</b> Smart Link Pass-Through</p>
<b>port</b>	<p>Select the port to configure.</p> <p><b>Values:</b> 1 or 2</p>
<b>edc-mode</b>	<p><b>Settings:</b> Auto, linear, limiting, CX1</p> <p><b>Default:</b> Auto</p> <p><b>* Note: See manufacturers documentation for parameter settings.</b></p>
<b>frequency-control</b>	<p><b>Settings:</b></p> <p>Channel number 1-65535</p> <p><b>* Note See manufacturers documentation for parameter settings</b></p>
<b>name</b>	<p>The name to be associated with this port.</p> <p><b>Values:</b> 0-63 characters</p>
<b>tx-dither-control</b>	<p><b>Default:</b> Disable</p> <p><b>* Note: See manufacturers documentation for parameter settings.</b></p>
<b>wavelength-control</b>	<p><b>Settings:</b></p> <p>Channel number 0-65535</p> <p><b>* Note See manufacturers documentation for parameter settings</b></p>
<b>name</b>	<p>The name to be associated with this port.</p> <p><b>Values:</b> 0-63 characters</p>
<b>port</b>	<p>Enable or disable this port.</p>
<b>fec</b>	<p><b>Settings:</b></p> <p><b>Amplitude Adjustment:</b> -128 to 127</p> <p><b>Phase Adjustment:</b> -128 to 127</p> <p><b>Default:</b> Disabled</p> <p><b>* Note: See manufacturers documentation for parameter settings.</b></p>
<b>fiber-auto-negotiation</b>	<p>When enabled, the Media Converter Module will negotiate with its link partner to determine the most optimal parameters for this connection. This applies to 1000 SFP modules only.</p> <p><b>Default:</b> Enabled</p>

## Set slot... cm-10gt

<b>Description</b>	Configure a cm-10gt media converter module.
<b>User Level</b>	Admin
<b>Syntax</b>	<pre> <b>*For SFP ports</b> set slot &lt;slot#&gt; cm-10g module [fiber-fault-alert disabled enabled] [link-mode standard smart-link-passthrough] [name &lt;name&gt;]  set slot &lt;slot#&gt; cm-10g [port 1 2] [edc-mode auto linear limiting cx1][frequency-control enable disable][channel &lt;1-65535&gt;][name &lt;text&gt;] [port enabled disabled] [tx-dither-control enable disabled] [wave-length-control enable disable][wavelength &lt;0-65535&gt;]  * Note: See manufacturers documentation for parameter settings.  <b>*For XFP ports</b> set slot &lt;slot#&gt; cm-10g [port 1 2] [fec enabled disabled][amplitude-adjustment &lt;-128 - 127&gt;][phase-adjustment &lt;-128 - 127&gt;][frequency-control enable disable][channel &lt;1-65535&gt;][name &lt;text&gt;] [port enabled disabled] [tx-dither-control enable disabled] [wave-length-control enable disable][wavelength &lt;0-65535&gt;]  * Note: See manufacturers documentation for parameter settings.  <b>*For copper Ethernet only</b> set slot &lt;slot#&gt; cm-10gt port 2 duplex [half auto] energy-efficient-ethernet [name &lt;text&gt;][enabled disabled] pause [disabled symmetrical asymmetrical-tx asymmetrical-rx] [port enabled disabled] </pre>
<b>fiber-fault-alert</b>	<p>When enabled, if the Media Converter Module detects a loss of signal on the fiber receiver, it will immediately disable its fiber transmitter signal on this port. This in effect, notifies the fiber link partner that an error condition exists on the fiber connection.</p> <p><b>Note:</b> This feature only takes effect if Fiber Negotiation has been turned off. When disabled, the Media Converter Module will not monitor for or generate Fiber Fault.</p>
<b>link-mode</b>	<p><b>Smart Link Pass-Through:</b> In this mode, the link state on one fiber connection is directly reflected through the Media Converter Module to the other fiber connection. If link is lost on one of the fiber connections, then the other fiber link will be brought down by the Media Converter.</p> <p><b>Standard:</b> In this mode, each fiber link can be brought up and down independently of each other. A loss of signal on either fiber connection can occur without affecting the other fiber connection.</p> <p><b>Default:</b> Smart Link Pass-Through</p>
<b>port</b>	<p>Select the port to configure.</p> <p><b>Values:</b> 1 or 2</p>

<b>edc-mode</b>	<p><b>Settings:</b> Auto, linear, limiting, CX1  <b>Default:</b> Auto  * <b>Note:</b> See manufacturers documentation for parameter settings.</p>
<b>frequency-control</b>	<p><b>Settings:</b>  Channel number 1-65535  * <b>Note:</b> See manufacturers documentation for parameter settings</p>
<b>name</b>	<p>The name to be associated with this module.  <b>Values:</b> 0-63 characters</p>
<b>tx-dither-control</b>	<p><b>Default:</b> Disable  * <b>Note:</b> See manufacturers documentation for parameter settings.</p>
<b>wavelength-control</b>	<p><b>Settings:</b>  Channel number 0-65535  * <b>Note:</b> See manufacturers documentation for parameter settings</p>
<b>name</b>	<p>The name to be associated with this port.  <b>Values:</b> 0-8 characters</p>
<b>port</b>	<p>Enable or disable this port.</p>
<b>fec</b>	<p><b>Settings:</b>  <b>Amplitude Adjustment:</b> -128 to 127  <b>Phase Adjustment:</b> -128 to 127  <b>Default:</b> Disabled  * <b>Note:</b> See manufacturers documentation for parameter settings.</p>
<b>duplex</b>	<p><b>The following selections are available:</b>  <b>Duplex:</b> Auto, Half  <b>Default:</b> Auto  This duplex configuration parameter will only be used for 1 gigabit SPF modules. For 10 gigabit modules, full duplex will always be advertised</p>
<b>energy-efficient-ethernet</b>	<p><b>Enabled:</b> When enabled, the media converter module will auto negotiate EEE with the attached EEE compliant devices/servers.  <b>Disabled:</b> The media converter module will not auto negotiate EEE with attached the EEE compliant devices/servers.  <b>Default:</b> Enabled</p>
<b>pause</b>	<p>The Media Converter Module can advertise the following Pause capabilities:</p> <ul style="list-style-type: none"> <li>● Symmetrical</li> <li>● Asymmetrical TX</li> <li>● Asymmetrical RX</li> </ul> <p><b>Note:</b> 1 Gigabit modules must have auto negotiation turned off on the fiber side in order for Pause to be advertised on the copper side.  <b>Default:</b> Asymmetrical RX</p>

**fiber-auto-negotiation** When enabled, the Media Converter Module will negotiate with its link partner to determine the most optimal parameters for this connection. This applies to 1000 SFP modules only.  
**Default:** Enabled

## Set slot... cm-4gpt

<b>Description</b>	Configure a cm-4gpt media converter module.
<b>User Level</b>	Admin
<b>Syntax</b>	<b>set slot &lt;slot#&gt; cm-4gpt [port&lt;1 2&gt;[port enabled disabled] [name &lt;text&gt;]</b> <b>Set slot &lt;slot#&gt; cm-4gpt [module] [fiber-fault-alert disabled enabled] [Link-mode standard smart-link-passthrough] [name &lt;text&gt;] [rate-select low high]</b>
<b>port</b>	Select the port to configure. <b>Values:</b> 1 or 2
<b>port</b>	Enable or disable this port.
<b>name</b>	The name to be associated with this port. <b>Values:</b> 0-8 characters
<b>fiber-fault-alert</b>	<b>Enabled:</b> If the media converter module detects a loss of fiber signal on its fiber receiver, it will disable its fiber transmitter on the same SFP. This, in effect, notifies the fiber link partner that an error condition exists on the fiber connection. <b>Disabled:</b> The module will take no action when a loss of signal is detected <b>Default:</b> Disabled.
<b>link-mode</b>	<b>Smart Link Pass-Through:</b> In this mode, the fiber link state on one fiber connection is directly reflected through the media converter module to the other fiber connection. Since this media converter is protocol independent, it monitors the Signal Detect indicator from the SFP and reflects this on the TX port of the other SFP by turning off the transmitter. When the signal (Link) get restored and Signal Detect becomes active, the affected transmitter will get re-enabled.  <b>Standard Mode:</b> In Standard Mode the media converter module will monitor the fiber link in the same manner. If the Signal Detect goes down the media converter module will out a 25MHz signal on the TX port of the other SFP.  <b>Default:</b> Smart Link Pass-Through
<b>name</b>	The name to be associated with this module. <b>Values:</b> 0-63 characters
<b>rate-select</b>	High Speed: When a multi-rate SFP is inserted, it is enabled for the higher speed of operation. Low Speed: When a multi-rate SFP is inserted, it is enabled for the slower speed of operation. <b>Default:</b> High

## Set slot... ex

<b>Description</b>	Configure a ex media converter module.
<b>User Level</b>	Admin
<b>Syntax</b>	<pre> set slot &lt;slot #&gt; ex module [interlink-fault-feedback enabled disabled] [link-mode standard smart-link-passthrough] [map-priority-to-egress-queue &lt;0-7&gt; &lt;0-3&gt;] [unidirectional-ethernet disabled ethernet-to-vdsl vdsl-to-ethernet]  set slot &lt;slot #&gt; ex ethernet [10baset-distance normal extended] 8021p-priority enabled disabled] [auto-negotiation enabled] [advertise &lt;10-full 10-half 100-full 100-half all&gt; disabled] [congestion-pol icy strict-queueing weighted queueing] [crossover auto mdi mdi-x] [default-priority &lt;0-7&gt;] [default-vlan-id &lt;0-4095&gt;] [discard-tagged-frames enable disabled] [discard untagged-frames enabled disabled] [downshift &lt;0-8&gt;] [egress-rate-limit none 64kbps 128kbps  192kbps 256kbps 320kbps 384kbps 512kbps 768kbps 1mbps 2mbps  3mbps 4mbps 5mbps 6mbps 7mbps 8mbps 9mbps 10mbps 20mbps 30mbps  40mbps 50mbps 60mbps 70mbps 80mbps 90mbps] [egress-rate-limit none 64kbps 128kbps 192kbps 256kbps 320kbps 384kbps 512kbps 768k bps 1mbps 2mbps 3mbps 4mbps 5mbps 6mbps 7mbps 8mbps 9mbps 10mbps  20mbps 30mbps 40mbps 50mbps 60mbps 70mbps 80mbps 90mbps] [filter -unknown-multicast enabled disabled] [filter-unknown-unicast enable disable] [ingress-rate-limit none 64kbps 128kbps 192kbps 256kbps 320kbps 384kbps 512kbps 768k bps 1mbps 2mbps 3mbps 4mbps 5mbps 6mbps 7mbps 8mbps 9mbps 10mbps  20mbps 30mbps 40mbps 50mbps 60mbps 70mbps 80mbps 90mbps] [ip-tos -priority enabled disabled] [name &lt;text&gt;] [pause disabled symmetrical asymmetrical-tx asymmetrical-rx] [port enabled disabled] [priority-precedence] 8021p ip-tos] [remap-priority &lt;0-7&gt; &lt;0-7&gt;] [vlan-tagging-action none untag tag double-tag] </pre>

```

set slot <slot #> ex vdsl [8021p-priority
enabled|disabled][congestion-policy strict-queueing|weighted
queueing][default-priority <0-7>][default-vlan-id
<0-4095>][discard-tagged-frames enable|disabled][discard
untagged-frames enabled|disabled][egress-rate-limit
none|64kbps|128kbps
|192kbps|256kbps|320kbps|384kbps|512kbps|768kbps|1mbps|2mbps
|3mbps|4mbps|5mbps|6mbps|7mbps|8mbps|9mbps|10mbps|20mbps|30mbps
|40mbps|50mbps|60mbps|70mbps|80mbps|90mbps][egress-rate-limit
none|64kbps|128kbps|192kbps|256kbps|320kbps|384kbps|512kbps|768k
bps|1mbps|2mbps|3mbps|4mbps|5mbps|6mbps|7mbps|8mbps|9mbps|10mbps
|20mbps|30mbps|40mbps|50mbps|60mbps|70mbps|80mbps|90mbps][fast-m
ode disabled|enabled][filter-unknown-multicast
enabled|disabled][filter-unknown-unicast
enable|disable][ingress-rate-limit
none|64kbps|128kbps|192kbps|256kbps|320kbps|384kbps|512kbps|768k
bps|1mbps|2mbps|3mbps|4mbps|5mbps|6mbps|7mbps|8mbps|9mbps|10mbps
|20mbps|30mbps|40mbps|50mbps|60mbps|70mbps|80mbps|90mbps][ip-tos
-priority enabled|disabled]low-bandwidth-alarm
downstream|upstream <0-90000>[name <text>][over-ride-profile
downstream|upstream [bitswapping <enable|disabled>][
max-datarate <128-101064>][max-interleave-delay
<0-16>][min-datarate <128-101064>][min-inp
<1-18>][signal-to-noise-ratio <30-240>][port
enabled|disabled][priority-precedence 8021p|ip-tos][profile-type
[auto <rate high-speed|long-range> <symmetry
asymmetric|symmetric>]|manual <1-33>][remap-priority <0-7>
<0-7>][role auto|local|remote] [vlan-tagging-action
none|untag|tag|double-tag]

```

- module** This command defines parameters which apply to the whole media converter module.
- interlink-fault-feed back** The status of the VDSL interface will be passed to its Ethernet interface. If the VDSL line link is lost the Ethernet link will be brought down.  
When Interlink Fault Feedback is disabled, the status of the VDSL interface will not be passed to its Ethernet interface.  
**Default:** Disabled.
- link-mode** **Standard:** In this mode, the Ethernet Extender module will not pass the state of the Ethernet interface across the Line connection to its peer. A loss on the Ethernet interface can occur without affecting the peer connection.  
**Smart-link-passthrough:** In this mode, the Ethernet Extender module will pass the state of the Ethernet interface across the Line connection to its peer. If the link is lost on the Ethernet connection, then the peer Ethernet connection will be brought down by the remote Ethernet Extender. This is accomplished by signalling Link Pass-Through across the VDSL line without bringing down the link.  
**Default:** standard

<b>Map Priority to Egress Queue</b>	<p>This is the <b>default</b> egress priority mapping for both the copper and fiber ports.</p> <p>Priority 0 (lowest priority).Queue 0  Priority 1.....Queue 0  Priority 2.....Queue 1  Priority 3.....Queue 1  Priority 4.....Queue 2  Priority 5.....Queue 2  Priority 6.....Queue 3  Priority 7 (highest priority).Queue 3</p>
<b>Unidirectional Ethernet</b>	<p>When enabled, this feature provides the ability to restrict the port to one-way traffic flow.</p> <p><b>Values:</b></p> <ul style="list-style-type: none"> <li>● Disabled</li> <li>● Ethernet to VDSL</li> <li>● VDSL to Ethernet</li> </ul> <p><b>Default:</b> Disabled</p>
<b>ethernet</b>	<p>This command defines parameters which apply to the ethernet port of the media converter module.</p> <p>These parameters apply to the Ethernet interface on this module.</p>
<b>10baset-distance</b>	<p><b>Normal:</b> the Media Converter copper link is in normal operating mode.</p> <p><b>Extended:</b> the Media Converter will boost the signal strength on its copper link.</p>
<b>8021p- priority</b>	<p>When enabled, the media converter module will use IEEE 802.1p tagged frame priority control to assign ingress frames to the appropriate priority egress queue.</p> <p><b>Default:</b> Enabled</p>
<b>auto-negotiation</b>	<p><b>Enabled:</b> Advertise on the copper link one of the following: 10-full, 10-half, 100-full, 100-half, or all.</p> <p><b>Disabled:</b> Do not advertise on the copper link.</p>
<b>congestion-policy</b>	<p>Select a method to be used when determining the order by which frames are sent from the four egress queues.</p> <p><b>Strict Priority Queuing</b> - The order is determined strictly by the priority of the queue. Frames in higher priority queues are always sent ahead of frames in lower priority queues.</p> <p><b>Weighted Fair Queuing</b> - This method allows lower priority frames to be intermixed with higher priority frames in the ratio of <b>(8, 4, 2, 1)</b>.</p> <p>The ratio for 8 highest priority sent frames will be as follows:</p> <p><b>8</b> highest priority frames from queue 3  <b>4</b> frames from queue 2  <b>2</b> frames from queue 1  <b>1</b> frame from queue 0</p>

<b>crossover</b>	<ul style="list-style-type: none"> <li>● <b>Auto-Detect</b>— automatically detects the Ethernet’s cable polarity</li> <li>● <b>MDI</b> —the cable’s polarity is straight-through</li> <li>● <b>MDI-X</b> —the cable’s polarity is crosscovered</li> </ul> <p><b>Default:</b> Auto</p>
<b>default-priority</b>	Specify a default VLAN priority to insert when tagging frames. <b>Default:</b> 0 <b>Data Options:</b> 0-7
<b>default-vlan-id</b>	Specify a default VLAN ID to insert when tagging frames. <b>Default:</b> 1 <b>Data Options:</b> 0-4095
<b>discard-tagged-frames</b>	When enabled, discards all VLAN tagged frames. <b>Default:</b> Off
<b>discard-untagged-frames</b>	When enabled, discards all VLAN untagged frames. <b>Default:</b> Off
<b>downshift</b>	When enabled, the number of retries the Media Converter Module will attempt to establish a fiber connection at 1000 Mbps before attempting a lower speed. <b>Default:</b> Off
<b>egress-rate-limit</b>	Restricts egress frames on the copper/vdsl port. <b>Default:</b> None <b>Data Options:</b> 64 kbps to 90 Mbps
<b>fast-mode</b>	Fast mode reduces frame latency when using shorter cable distances. <b>Default:</b> Disabled <b>Note:</b> Using InterLink override values for upstream and downstream SNR and/or INP values may disable Fast mode.
<b>filter-unknown-multicast</b>	When enabled, multicast frames with unknown destination addresses are not allowed to egress this port. <b>Default:</b> Disabled
<b>filter-unknown-unicast</b>	When enabled, unicast frames with unknown destination addresses are not allowed to egress this port. <b>Default:</b> Disabled
<b>ingress-rate limit</b>	Restricts egress frames on the copper/vdsl port. <b>Default:</b> None <b>Data Options:</b> 64 kbps to 90 Mbps
<b>ip-tos-priority</b>	When enabled, the media converter module will use IPv4 Diffserv or IPv6 traffic class field to assign ingress frames to the appropriate priority egress queue. <b>Default:</b> Enabled
<b>low-bandwidth-alarm</b>	When the upstream or downstream link is established, the Ethernet Extender module will check the low bandwidth value. If the data rate is below the threshold value, an SNMP trap will be generated. <b>Values:</b> 0-90000 (0 means off)
<b>name</b>	The name to be associated with this port. <b>Values:</b> 0-8 characters

<b>over-ride-profile</b>	<p>Allows you to override advance VDSL settings:          Select upstream or downstream to configure the following:  <b>max-datarate:</b> 128-101064 kbps  <b>max-interleave-delay:</b> 0-16 ms  <b>min-datarate:</b> 128-101064  <b>min-inp:</b> 1-18  <b>signal-to-noise-ratio:</b> 30-240  <b>bitswapping:</b> enabled/disabled  <b>Note:</b> Advanced VDSL settings are valid only for Ethernet Extenders that have been configured with a role of Local</p>
<b>bitswapping</b>	<p>As line conditions change, bitswapping allows the modem to swap bits around different channels without retraining as each channel becomes more or less capable. If bitswapping is disabled, the modem will need to retrain in order to adapt to changing line conditions.  <b>Default:</b> Enabled</p>
<b>max-datarate</b>	<p>The maximum data rate of the VDSL link  <b>Values:</b> 128 - 101064 kbps</p>
<b>max-interleave-delay</b>	<p>Interleaving is a method of taking packets, chopping them up into smaller bits and then rearranging them so that once contiguous data is now spaced further apart into a noncontinuous stream. This provides better noise protection but increases latency. Enter the maximum acceptable gap in the data.  <b>Values:</b> 128 - 101064 kbps</p>
<b>min-datarate</b>	<p>The minimum data rate of the VDSL link  <b>Values:</b> 128 - 101064 kbps</p>
<b>signal-to-noise-ratio</b>	<p>The Ethernet Extender module will attempt to maintain the desired SNR value by adjusting line settings. A larger dB number will result in less line errors and a more stable connection, but may result in slower speeds.  <b>Values:</b> 30-240 (3-24 dB)</p>
<b>port</b>	<p>Enable or disable this port.</p>
<b>priority-precedence</b>	<p>When both 802.1p priority and TOS priority are selected, you can select which of the two priorities takes precedence.  <b>Default:</b> 802.1p</p>
<b>profile-type</b>	<p>When both 802.1p priority and TOS priority are selected, you can select which of the two priorities takes precedence.  <b>Default:</b> 802.1p</p>
<b>auto</b>	<p>Select profile type "auto" to select either high speed or long range and symmetry parameter.</p>
<b>manual</b>	<p>Select profile type "manual" to select from a profile list. Type ? to see complete list.  <b>Values:</b> 1-33</p>
<b>high-speed</b>	<p>In this mode, the VDSL connection will be optimized for maximum attainable speeds.</p>
<b>long-range</b>	<p>In this mode, the VDSL connection will be optimized for distance and the achievable distance will be up to 1 mile (3km).</p>

<b>role</b>	<p>If both Ethernet Extenders are configured for Auto mode, a proprietary method of detection is implemented for each attempt to synchronize the local and remote Ethernet Extenders modules. However, it is preferable to set one Ethernet Extender module to local and the other Ethernet Extender module to remote since this may result in slightly faster training times and direct control over their roles.</p> <p><b>Local (CO):</b> This Ethernet Extender module is set to local mode of operation.</p> <p><b>Remote (CPE):</b> This Ethernet Extender module is set to the Remote mode of operation.</p>
<b>vlan-tagging-actions</b>	<p>Define the VLAN tagging action to take on a egress frame.</p> <ul style="list-style-type: none"> <li>● Normal - Take no action.</li> <li>● Untag - Remove any existing tag.</li> <li>● Tag <ul style="list-style-type: none"> <li>Insert tag with configured VLAN ID and VLAN priority if original frame is untagged.</li> <li>Replace tag with configured VLAN ID and VLAN priority if original frame is tagged.</li> </ul> </li> <li>● Double tag - Append a tag with configured VLAN ID and VLAN priority.</li> </ul> <p><b>Default:</b> Normal</p>

## Show slot \* command

<b>Description</b>	Displays what module is inserted in each slot.
<b>User Level</b>	Admin, Operator
<b>Syntax</b>	<code>show slot *</code>

## Show slot # command

<b>Description</b>	Depending on the module inserted information about that specific slot will be displayed.
<b>User Level</b>	Admin, Operator
<b>Syntax</b>	<pre> slow slot &lt;slot #&gt; fiber [config sfp statistics] [sfp thresholds] show slot &lt;slot #&gt; fiber [1 2] config show slot &lt;slot #&gt; copper [config statistics] show slot &lt;slot #&gt; port [1 2] [config xfp sfp] [xfp sfp thresholds] show slot &lt;slot #&gt; alerts show slot &lt;slot #&gt; details show slot &lt;slot #&gt; link-test show slot &lt;slot #&gt; module show slot &lt;slot #&gt; port show slot &lt;slot #&gt; power schedule show slot &lt;slot #&gt; switches </pre>

## Show chassis alerts

<b>Description</b>	Displays the local alert log.
<b>User Level</b>	Admin, Operator
<b>Syntax</b>	<code>show chassis alerts</code>

## Show chassis details

<b>Description</b>	Displays the chassis firmware and serial number info.
<b>User Level</b>	Admin, Operator
<b>Syntax</b>	<code>show chassis details</code>



# User Commands

---

## Commands for active sessions

### Admin

<b>Description</b>	Changes a Operator-level user to the Admin user. When you press <b>Enter</b> after you type this command, you will be prompted for the Admin password.
<b>User Level</b>	Operator
<b>Syntax</b>	<code>admin</code>

### Help

<b>Description</b>	Displays help on using the command line interface (CLI).
<b>User Level</b>	Operator, Admin
<b>Syntax</b>	<code>help</code>

### Logout

<b>Description</b>	Logs the user out from the MCR-MGT Management Module.
<b>User Level</b>	Operator, Admin
<b>Syntax</b>	<code>logout</code>

### Menu

<b>Description</b>	Switches from a command line based interface to Menu mode of operation.
<b>User Level</b>	Operator, Admin
<b>Syntax</b>	<code>menu</code>

### Ping

<b>Description</b>	This command checks to see if a given host is reachable via an IP message. The specific message used is called a ping.
<b>User Level</b>	Operator, Admin
<b>Syntax</b>	<code>ping [destination] [&lt;packet_size&gt;] [&lt;#_of_packets&gt;]</code>
<b>destination</b>	This can be a "hostname" or an "IP address" The name (DNS resolvable host name) or IP address of the machine you are trying to ping.
<b>packet-size</b>	Enter the number of data bytes to be sent. The default is 100 bytes.
<b>#of packets</b>	Enter the number of the packets you want to send. The default is 10.

## Screen

<b>Description</b>	Switches from a command line based interface to Menu mode of operation.
<b>User Level</b>	Operator, Admin
<b>Syntax</b>	<b>screen</b>

## Set Termttype

<b>Description</b>	Sets the type of terminal being used on the console port.
<b>User Level</b>	Operator, Admin
<b>Syntax</b>	<b>set termttype [type]</b>
<b>type</b>	Specifies the type of terminal connected to the console port <ul style="list-style-type: none"> <li>● Dumb</li> <li>● WYSE60</li> <li>● VT100</li> <li>● ANSI</li> <li>● TVI925</li> <li>● IBM3151TE</li> <li>● VT320 (specifically supporting VT320-7)</li> <li>● HP700 (specifically supporting HP700/44)</li> </ul>

## Syslog Console

<b>Description</b>	Starts/stops or displays the status of the syslog console.
<b>User Level</b>	Admin, Operator
<b>Syntax</b>	<b>syslog console [start stop]</b>
	<b>syslog console [status]</b>
<b>start</b>	Start or stop console logging. When console logging is enabled, syslog messages will be echoed to the console. These messages are filtered based on the level set in the (remote) syslog options.
<b>stop</b>	
<b>status</b>	Displays the current console logging status (enabled or disabled).

## Show Termttype

<b>Description</b>	Shows the terminal type for the current session.
<b>User Level</b>	Admin, Operator
<b>Syntax</b>	<b>show termttype</b>

## Version

<b>Description</b>	Displays firmware version and build.
<b>User Level</b>	Operator, Admin
<b>Syntax</b>	<b>version</b>

# Configuring Users

## Add User

<b>Description</b>	Add a new user to the local user database.
<b>User Level</b>	Admin
<b>Syntax</b>	<b>add user &lt;username&gt;</b>

**username** The name of the user, without spaces. When you finish the command and press Enter, you will be prompted to enter and re-enter a password for the user.

## Delete User

**Description** Deletes a user.  
**User Level** Admin  
**Syntax** `delete user <config_user>`  
**delete-user** You can see a list of users that can be deleted by typing `delete user ?`. You can not delete the `admin` user.

## Set User

**Description** Sets users settings.  
**User Level** Admin  
**Syntax** `set user username [level] [password]`  
**username** The name of an existing user in the local user database.  
**level** The access that a user is allowed:

- **Admin**—The admin level user has total access to the MCR-MGT Management Module. You can create more than one admin user account but we recommend that you only have one. They can monitor and configure the MCR-MGT Management Module.
- **Operator**—The Operator can fully operate the MCR-MGT Management Module but can not change any configurable parameters.

**password** The password the user will need to enter to login to the MCR-MGT Management Module. This case-sensitive field accepts a maximum of 16 characters.

## Show User

**Description** Shows user configuration settings.  
**User Level** Admin, Operator  
**Syntax** `show user <configured_user>|. .`  
**configured user** Show the settings for the specified user.  
**.** Show the settings for the current user.



# Network Commands

---

## SNMP Commands

### Add Community

<b>Description</b>	Adds an SNMP community (version 1 and version 2).
<b>User Level</b>	Admin
<b>Syntax</b>	<b>add community</b> <community_name> <config-host> <internet-address> [none readonly readwrite]
<b>community-name</b>	<b>SNMP community name&gt;</b>
<b>config- host</b>	The host name or IP address of the SNMP community that will send requests to the MCR-MGT Management Module.
<b>internet-address</b>	
<b>none readonly  readwrite</b>	The permission rights for this SNMP community.

### Set SNMP

<b>Description</b>	Configures SNMP settings.
<b>User Level</b>	Admin
<b>Syntax</b>	<b>set snmp</b> [contact] [location][readonly user] [readwrite user] [engine-id-suffix]
<b>contact</b>	The name and contract information of the person who manages this SMNP node.
<b>location</b>	The physical location of the SNMP node.
<b>readonly user</b>	(SNMP version 3) Specified user can only view SNMP variables.
<b>readwrite user</b>	(SNMP version 3) User that can view and edit SNMP variables.
<b>engine-id- suffix</b>	This is the engine ID suffix which will be used with V3 traps. It is used to help identify the trap sender to the trap receiver. It is a unique identifier of the SNMP agent in the domain. By default the Engine ID is composed using the serial number of the Management Module which should make it unique. If you wish to assign a different engine ID to this node, use the "custom" keyword followed by the engine ID suffix string. If you want to revert to the default engine ID, use the "default" keyword. When changing the engine ID, the string entered in this field will be combined with other required elements to form the EngineID. It is up to the user to ensure that this will be a unique string.

## Set SNMP V3-Security

<b>Description</b>	Configures SNMP settings for the Version 3 read-write, read-only and trap user(s).
<b>User Level</b>	Admin
<b>Syntax</b>	<b>set snmp v3-security</b> [usertype] [security-level] [auth-algorithm] [auth-password] [privacy-algorithm] [privacy-password]
<b>usertype</b>	Specify the security parameters for each of the "readonly" and "readwrite" user types. This parameter defines which of the two user types this applies to. Valid options are; readonly readwrite
<b>security-level</b>	Select the security level for the user. This must match the configuration set up in the SNMP manager. <b>Data Options:</b> <ul style="list-style-type: none"> <li>• <b>None</b>—No security is used.</li> <li>• <b>Auth</b>—User authentication is used.</li> <li>• <b>Auth/Priv</b>—User authentication and privacy (encryption) settings are used.</li> </ul> <b>Default:</b> None
<b>auth-algorithm</b>	Specify the authentication algorithm that will be used for the user. <b>Data Options:</b> MD5, SHA <b>Default:</b> MD5
<b>auth-password</b>	If you specify this parameter you will be prompted for the password as well as to re-type the password after you press enter on this command.
<b>privacy-algorithm</b>	Specify the encryption algorithm to be used with this user. <b>Data Options:</b> DES, AES <b>Default:</b> DES
<b>privacy-password</b>	If you specify this parameter you will be prompted for the password as well as to re-type the password after you press enter on this command.

## Set snmp-trap common

<b>Description</b>	Adds an SNMP host to which trap messages will be sent.
<b>User Level</b>	Admin
<b>Syntax</b>	<b>set snmp-trap common</b> [inform-retries] [inform-timeout] [level] [mode]
<b>inform-retries</b>	This is only used for "Inform" traps. Select the number of times the trap will be sent if no acknowledgement is received. The default is 3.
<b>inform-timeout</b>	This is only used for "Inform" traps. Select the number of seconds to wait for the acknowledgement of the trap. The default is 1 second.
<b>level</b>	Choose the event level that triggers an SNMP trap to be sent. <b>Data Options:</b> system-level-fault, module-level-fault, persistent-error, one-time-error, significant-event, normal-operation
<b>mode</b>	Enable or Disable the sending of traps.

## Set snmp-trap entry

<b>Description</b>	Adds an SNMP host to which trap messages will be sent. Up to 4 trap host entries can be defined.
<b>User Level</b>	Admin

<b>Syntax</b>	<b>set snmp-trap entry [entry#] [community] [internet-address] [mode] [type] [udp] [version]</b>
<b>entry #</b>	Enter the entry number. Valid options are 1 - 4.
<b>community</b>	The name of the group that devices and management stations running SNMP belong to. This only applies to SNMP version 1 and version 2c.
<b>internet-address</b>	The IP address of the SNMP manager that will send requests to the MCR-MGT module. If the address is 0.0.0.0, any SNMP manager matching the <b>Community</b> name configured, can access the MCR-MGT module. If you specify a network address, for example 172.16.0.0, any SNMP manager residing on the 172.16.x.x subnet with a matching <b>Community</b> name can access the MCR-MGT module. <b>Field Format:</b> IPv4 or IPv6 address
<b>mode type</b>	Enable or Disable this trap host entry. This field is ignored for trap host version v1" Data Options: Trap - Management module will send traps via a TRAP_PDU or TRAP2-PDU not expecting any response from the specified host. Inform - Management module will send traps via an INFORM_PDU, expecting a response from the specified host. Default: Trap
<b>udp</b>	Enter the UDP port number that the SNMP trap host is listening on for UDP traps. <b>Default:</b> 162
<b>version</b>	Defines the SNMP version of the traps sent to the specified host. If v3 is selected then the SNMP trap v3 user will be used to authenticate the trap with the specified host. Valid options are v1, v2c or v3. <b>Default:</b> v1

## Set snmp-trap v3

<b>Description</b>	Defines the parameters associated with the SNMP trap user for V3 traps.
<b>User Level</b>	Admin
<b>Syntax</b>	<b>set snmp-trap v3 [username] [security-level] [auth-algorithm] [auth-password] [privacy-algorithm] [privacy-password]</b>
<b>username</b>	This field identifies the system sending the traps to the host receiving the traps. Same user name is used for all v3 traps sent by this system.
<b>security-level</b>	Select the security level for the user. This must match the configuration set up in the SNMP manager. <b>Data Options:</b> <ul style="list-style-type: none"> <li>● <b>None</b>—No security is used.</li> <li>● <b>Auth</b>—User authentication is used.</li> <li>● <b>Auth/Priv</b>—User authentication and privacy (encryption) settings are used.</li> </ul> <b>Default:</b> None
<b>auth-algorithm</b>	Specify the authentication algorithm that will be used for the user. <b>Data Options:</b> MD5, SHA <b>Default:</b> MD5
<b>auth-password</b>	If you specify this parameter you will be prompted for the password as well as to re-type the password after you press enter on this command.

- privacy-algorithm** Specify the encryption algorithm to be used with this user.  
**Data Options:** DES, AES  
**Default:** DES
- privacy-password** If you specify this parameter you will be prompted for the password as well as to re-type the password after you press enter on this command.

## Delete Community

- Description** Deletes an SNMP community (version 1 and version 2).  
**User Level** Admin  
**Syntax** **delete community** <config\_community\_number>  
**config community number** When you add an SNMP community, it gets assigned to a number. To delete the SNMP community, you need to specify the number of the community that you want to delete. To see which community is assigned to what number, type the **show snmp** command.

## Show SNMP

- Description** Shows SNMP settings, including communities and traps.  
**User Level** Admin, Operator  
**Syntax** **show snmp**

# Hosts Commands

## Add Host

<b>Description</b>	Adds a host to the MCR-MGT Management Module host table.
<b>User Level</b>	Admin
<b>Syntax</b>	<b>add host</b> <hostname> <IP_address>
	<b>add host</b> <hostname> <b>fqdn</b> <text>
<ip-address>	This can be an IPv4 or IPv6 address
<hostname>	The name of the host. This is used only for the MCR-MGT Management Module configuration. <b>Field Format:</b> Up to 14 characters, no spaces.
<b>fqdn</b>	<b>fqdn</b> When you have DNS defined in the MCR-MGT Management Module, you can enter a DNS resolvable fully qualified domain name (note: FQDN's are excluded as accessible hosts when <b>IP Filtering</b> is enabled).

## Delete Host

<b>Description</b>	Deletes a host from the MCR-MGT Management Module host table.
<b>User Level</b>	Admin
<b>Syntax</b>	<b>delete host</b> <config_host>
<b>Option</b>	<config_host>
	You can see a list of hosts that can be deleted by typing <b>delete host?</b> .

## Set Host

<b>Description</b>	Modifies a host entry in the MCR-MGT Management Module host table.
<b>User Level</b>	Admin
<b>Syntax</b>	<b>set host</b> <b>_default</b> <config_host> <IP_address>
	<b>set host</b> <config_host> <b>fqdn</b> <text>
<b>Options</b>	<config_host>
	The name of the host. This is used only for the MCR-MGT Management Module configuration. <b>Field Format:</b> Up to 14 characters, no spaces.
<IP_address>	Assign a specific IP address and subnet to the MCR-MGT Management Module's Ethernet interface.
<b>fqdn</b>	When you have DNS defined in the MCR-MGT Management Module, you can enter a DNS resolvable fully qualified domain name (note: FQDN's are excluded as accessible hosts when <b>IP Filtering</b> is enabled).

## Show Hosts

<b>Description</b>	Shows the MCR-MGT Management Module host table.
<b>User Level</b>	Operator, Admin
<b>Syntax</b>	<b>show hosts</b>

## Add Authorized Host

<b>Description</b>	Adds a host to the MCR-MGT Management Module authorized host table.
<b>User Level</b>	Admin
<b>Syntax</b>	<b>add authorized-host ip-address</b> <IP_address> <description>
	<b>add authorized-host mac-address</b> <mac_address> <description>
<IP_address>	This can be an IPv4 or IPv6 address
<mac address>	The format is aa-bb-cc-dd-ee-ff.
<description>	This is a description which will help you identify this host.

## Delete Authorized Host

<b>Description</b>	Deletes a host from the MCR-MGT Management Module authorized host table.
<b>User Level</b>	Admin
<b>Syntax</b>	<b>delete authorized-host ip-address</b> <IP_address>
	<b>delete authorized-host mac-address</b> <mac_address>
<IP_address>	IP address of a host in the table
<mac_address>	MAC address of a host in the table

## Set Authorized Host

<b>Description</b>	Enables or Disables the use of the authorized host table. When enabled, only hosts which appear in the table will be given access to the MCR-MGT Management Module.
<b>User Level</b>	Admin
<b>Syntax</b>	<b>set authorized-hosts mode</b> [enabled disabled]

## Show Authorized Hosts

<b>Description</b>	Shows the status of the authorized host feature. Either Enabled or Disabled.
<b>User Level</b>	Admin, Operator
<b>Syntax</b>	<b>show authorized-hosts</b>

# DNS Commands

## Add DNS

<b>Description</b>	Adds a DNS entry.
<b>User Level</b>	Admin
<b>Syntax</b>	<b>add dns</b> <IP_address>
<b>Option</b>	<IP_address>

You can specify the IP addresses for up to four DNS (Domain Name Servers) hosts in your network.

## Delete DNS

<b>Description</b>	Deletes a DNS entry.
<b>User Level</b>	Admin
<b>Syntax</b>	<b>delete dns</b> <config_dns_addr>
<b>Option</b>	<config_dns_addr>

You can view a list of configured DNS server IP addresses to choose from by typing **delete dns?**.

## Show DNS

<b>Description</b>	Shows all DNS entries, even those supplied by DHCP/BOOTP when applicable.
<b>User Level</b>	Admin, Operator
<b>Syntax</b>	<b>show dns</b>

# Gateway Commands

## Add Gateway

<b>Description</b>	Adds a gateway. You can configure up to twenty gateways.
<b>User Level</b>	Admin
<b>Syntax</b>	<pre>add gateway &lt;config_host&gt; default  add gateway &lt;config_host&gt; host &lt;dest_IP_addr&gt;  add gateway &lt;config_host&gt; network &lt;dest_IPv4_addr&gt; &lt;dest_IPv6_addr&gt; [&lt;subnet_bits_0-32&gt; &lt;prefix_bits_0-128&gt;]  add gateway specify-gateway ipv6tunnel &lt;tunnel_name&gt; default  host &lt;dest_IP_addr&gt;  network &lt;dest_IPv4_addr&gt; &lt;dest_IPv6_addr&gt; [&lt;subnet_bits_0-32&gt; &lt;prefix_bits_0-128&gt;]</pre>
<b>Options</b>	<p><b>&lt;config_host&gt;</b></p> <p>Select this option when a host is being used at the route gateway.  <b>Default:</b> Enabled, None</p> <p><b>default host network</b></p> <p><b>ipv6tunnel &lt;tunnel_name&gt;</b></p> <p><b>&lt;dest_IP_addr&gt;</b></p> <p><b>&lt;subnet_bits&gt; &lt;prefix_bits&gt;</b></p> <p>When the route is a <b>Network</b> route, you must specify the network's subnet mask.</p>

## Delete Gateway

<b>Description</b>	Deletes a gateway.
<b>User Level</b>	Admin
<b>Syntax</b>	<pre>delete gateway &lt;config_gateway_host&gt;</pre>
<b>Option</b>	<p><b>&lt;config_gateway_host&gt;</b></p> <p>You can view the configured gateways that can be deleted by typing <code>delete gateway?</code>.</p>

## Set Gateway

<b>Description</b>	Modifies an existing gateway.
<b>User Level</b>	Admin
<b>Syntax</b>	<pre>set gateway &lt;config_gateway_host&gt; default  set gateway &lt;config_gateway_host&gt; host &lt;destination_ip&gt;  set gateway &lt;config_gateway_host&gt; network &lt;dest_IPv4_addr&gt; &lt;dest_IPv6_address&gt; &lt;prefixbits_mask&gt;</pre>
<b>Options</b>	<p><b>&lt;config_gateway_host&gt;</b></p> <p>You can view the configured gateways that can be deleted by typing <code>delete gateway?</code>.</p> <p><b>default host network</b></p>

*<destination\_ip>*  
*<prefixbits\_mask>*

## Show Gateways

<b>Description</b>	Shows configured gateways.
<b>User Level</b>	Operator, Admin
<b>Syntax</b>	<b>show gateways</b>

# Logging Commands

## Set Syslog

<b>Description</b>	Configures the system syslog.
<b>User Level</b>	Admin
<b>Syntax</b>	<b>set syslog</b> [ <b>level</b> emergency alert critical error warning notice info debug] [ <b>primary-host</b> <config_host>] [ <b>secondary-host</b> <config_host>]
<b>level</b>	Set level for syslog.
<b>primary-host</b>	Sets the primary host address for syslog messages to be sent to.
<b>secondary-host</b>	Sets the secondary host address for syslog messages to be sent to.

## Show Syslog

<b>Description</b>	Shows the syslog settings.
<b>User Level</b>	Admin, Operator
<b>Syntax</b>	<b>show syslog</b>

## Set event-log

<b>Description</b>	Configures the local system log.
<b>User Level</b>	Admin
<b>Syntax</b>	<b>set event-log [level] [mode]</b>
<b>level</b>	Choose the alert level that will trigger a notification to be sent to the local log. <b>Data Options:</b> System-level Fault Module Level Fault Persistent Error One-time error Significant Event Normal Operation. The level selected is the minimum trigger level with the "Normal Operation" being the least severe and "System-level Fault" being the most severe. The level selected will include alerts of that level and all more severe levels above it. <b>Default:</b> Normal Operation
<b>mode</b>	Enable or disable the local event log.

# IPv6 Tunnels

## Add IPv6tunnel

<b>Description</b>	Adds a new IPv6 tunnel.
<b>User Level</b>	Admin
<b>Syntax</b>	<code>add ipv6tunnel &lt;tunnel_name&gt;</code>
<b>tunnel name</b>	Adds an IPv6 tunnel.

## Set IPv6tunnel

<b>Description</b>	Configures the specified IPv6 tunnel.
<b>User Level</b>	Admin
<b>Syntax</b>	<code>set ipv6tunnel &lt;config-tunnel-name&gt; [mode manual teredo 6to4] [gateway &lt;interface&gt;] [remote-host &lt;config_host&gt;]</code>

**config-tunnel-name**  
**mode**

**Specify a IPv6 tunnel name.**

The method or protocol that is used to create the IPv6 tunnel.

- **Manual**—When enabled, the MCR-MGT Management Module will manually create the IPv6 tunnel to the specified **Remote Host** through the specified **Interface**.
- **6to4**—When enabled, the MCR-MGT Management Module will broadcast to the multicast address 192.88.99.1 through the specified **Interface**. When the closest 6to4 router responds, it will create the IPv6 tunnel, encapsulating and decapsulating IPv6 traffic sent to and from the MCR-MGT Management Module.
- **Teredo**—When enabled, the Teredo protocol encapsulates the IPv6 packet as an IPv4 UDP message, allowing it to pass through most network address translator (NAT) boxes and create an IPv6 tunnel to the specified **Remote Host** (a Teredo server) through the specified **Interface**.

**Default:** Manual

**gateway**

The interface that the MCR-MGT Management Module is going to use to access the Remote Host.

**Default:** Ethernet 1

**remote-host**

The IPv4 host that can access the IPv6 network when the **Mode** is **Manual**.

The Teredo server when the **Mode** is **Teredo**.

**Default:** None

## Show IPv6tunnel

<b>Description</b>	Shows the specified IPv6 tunnel settings.
<b>User Level</b>	Admin
<b>Syntax</b>	<code>show ipv6tunnel &lt;config-tunnel-name&gt;</code>

## Delete IPv6tunnel

<b>Description</b>	Controls the state of all IPsec tunnels.
<b>User Level</b>	Admin
<b>Syntax</b>	<code>delete ipv6tunnel &lt;config-tunnel-name&gt;</code>
<b>config tunnel name</b>	<code>&lt;config-tunnel-name&gt;</code>

Deletes an IPv6 tunnel. If a tunnel is associated with a route, it cannot be deleted until the route is either changed or deleted.



# Administration Commands

---

## Administration Commands

### Reboot

**Description** Reboots the MCR-MGT Management Module. You will be prompted to save configuration to FLASH, if there have been unsaved configuration changes.

**User Level** Admin, Operator

**Syntax** `reboot`

### Reset Factory

**Description** Resets the MCR-MGT Management Module to the factory configuration.

**User Level** Admin

**Syntax** `reset factory`

### Set Firmware auto-update

**Description** Automatically updates all managed Media Converter Modules with the bundled firmware.

**User Level** Admin

**Syntax** `set firmware auto-update [enabled | disabled]`

### Show Firmware auto-update

**Description** Shows the status of the update Media Converter Modules firmware feature. Shows banded version firmware for each managed Media Converter Module.

**User Level** Admin

**Syntax** `show firmware auto-update`

### Save

**Description** Saves the configuration to FLASH.

**User Level** Admin

**Syntax** `save`

### Set Bootup

**Description** Specifies the TFTP host and pathname for files to be loaded after a MCR-MGT Management Module reboot.

**User Level** Admin



# TFTP File Transfer Commands

## Netload configuration and firmware

**Note:** *To download firmware, you will be asked to agree with Perle's Licensing Agreement and Privacy Policy. Type y to agree that you have read and understand these agreements. The firmware download will then continue.*

**Description** Transfers a file from a remote host to the MCR-MGT Management Module using the TFTP protocol.

**User Level** Admin

**Syntax** `netload text-config|firmware|configuration <hostname/IP_address> <filename>`

**Options**

**text-config**  
Specify this option if you are uploading a text-based configuration file to the MCR-MGT Management Module from a TFTP server.

**firmware**  
Specifies that you are going to download a new firmware file to the MCR-MGT Management Module.

**configuration**  
Specifies that you are going to download a new configuration file to the MCR-MGT Management Module.

`<hostname/IP_address>`  
The IP address or host name where the file you are downloading to the MCR-MGT Management Module resides. If you are using a host name, it must be resolved in either the MCR-MGT Management Module's **Host Table** or a DNS server.

`<filename>`  
The complete path and file name of the file you are downloading to the MCR-MGT Management Module (this path should be relative to the default path of your TFTP server, which may or may not allow drive letters).

## Netsave configuration

**Description** Transfers a file from the MCR-MGT Management Module to a remote host using the TFTP protocol.

**User Level** Admin

**Syntax** `netsave configuration|diagnostic-file|serialt-buf|text-config <hostname/IP_address> <filename>`

**Options**

**configuration**  
Specifies that you are going to upload a configuration file from the MCR-MGT Management Module to the specified host or IP address.

**diagnostic-file**  
Specifies that you are going to upload a diagnostics file from the MCR-MGT Management Module to the specified host or IP address.

**serialt-buf**  
Specifies that you are going to upload the contents of the serial trace buffer.

**text-config**  
Specifies that you are going to upload the configuration in text format.

*<hostname/IP\_address>*

The IP address or host name for where the file you are uploading from the MCR-MGT Management Module is going. If you are using a host name, it must be resolved in either the MCR-MGT Management Module's **Host Table** or a DNS server.

*<filename>*

The complete path and file name for the file you are uploading from the MCR-MGT Management Module (this path should be relative to the default path of your TFTP server, which may or may not allow drive letters).

# Keys and Certificates Commands

## Netload keys

**Description** Loads certificates and keys into the MCR-MGT Management Module using TFTP.

**User Level** Admin

**Syntax** `netload ssl certificate|private-key <hostname/IP_address>  
<filename>`

`netload ssh-server user <config_user> public-key ssh-2 rsa|dsa  
<hostname/IP_address> <filename>`

**Options** `ssl certificate|private-key|ca-list`

If you are using the secure version of the WebManager (HTTPS), or LDAP authentication with TLS, then you need to download the SSL/TLS private key and CA list to make a secure connection.

### public-key ssh-2

Specify ssh-2 when you are using SSH version 2.

### rsa|dsa

When downloading keys to the MCR-MGT Management Module, specify the authentication method used by the key.

### ssh-server user

The user that the SSH key is for.

`<hostname/IP_address>`

Enter the host or IP address that contains the certificate/key you are downloading to the MCR-MGT Management Module. If you are using a host name, it must be resolved in either the MCR-MGT Management Module's **Host Table** or a DNS server.

`<filename>`

Enter the complete path and file name of the certificate/key you are downloading to the MCR-MGT Management Module.

## Netsave keys

**Description** Uploads certificates and keys from the MCR-MGT Management Module to a remote host using TFTP.

**User Level** Admin

**Syntax** `netsave ssh-server public-key ssh-2 rsa|dsa <hostname/IP_address>  
<filename>`

**Options** `rsa|dsa`

When uploading SSH keys from the MCR-MGT Management Module, specify the SSH authentication method used by the SSH key.

`<hostname/IP_address>`

The IP address or host name for where the SSH key you are uploading from the MCR-MGT Management Module is going. If you are using a host name, it must be resolved in either the MCR-MGT Management Module's **Host Table** or a DNS server.

*<filename>*

The complete path and file name for the file you are uploading from the MCR-MGT Management Module (this path should be relative to the default path of your TFTP server, which may or may not allow drive letters).

## Netload Media Converter Modules

**Note:** *To download firmware, you will be asked to agree with Perle's Licensing Agreement and Privacy Policy. Type y to agree that you have read and understand these agreements. The firmware download will then continue.*

**Description** Loads firmware to Media Converter Modules.

**User Level** Admin

**Syntax** `netload media-converter firmware <slot #> <hostname/IP_address>  
<filename>`

**Options** `slot`

The slot number of the Media Converter Module you wish to download the firmware to.

*<hostname/IP\_address>*

Enter the host or IP address that contains the firmware file you are downloading to the Media Converter Module. If you are using a host name, it must be resolved in either the MCR-MGT Management Module's **Host Table** or a DNS server.

*<filename>*

Enter the complete path and file name of the firmware file you are downloading to the Media Converter Module.

## Netload Serialt-buf

**Description** Loads serial trace buffer data onto the management module.

**User Level** Admin

**Syntax** `netload serialt-buf <text>`

**Options** *<text>*

The name of the serial trace buffer file to be downloaded.

## Netload sntp-keys

**Description** Loads sntp keys into the MCT-MGT management module.

**User Level** Admin

**Syntax** `netload sntp-keys <filename>`

**Options** *<filename>*

Enter the complete path and file name of the sntp key file you are downloading to the Media Converter Module.



# Time Commands

---

## Time Commands

### Set Time

<b>Description</b>	Sets the MCR-MGT Management Module's system clock.
<b>User Level</b>	Admin
<b>Syntax</b>	<code>set time &lt;hh:mm[:ss]&gt;</code>
<b>Option</b>	<code>&lt;hh:mm[:ss]&gt;</code>

### Set Timezone

<b>Description</b>	Sets the MCR-MGT Management Module's time zone name and its offset from Greenwich Mean Time (UTC).
<b>User Level</b>	Admin
<b>Syntax</b>	<code>set timezone [name &lt;string&gt;] [offset + -&lt;hh[:mm]&gt;]</code>
<b>name</b>	The name of the time zone to be displayed during standard time. <b>Field Format:</b> Maximum 4 characters and minimum 3 characters (do not use angled brackets <>)
<b>offset</b>	The offset from UTC for your local time zone. <b>Field Format:</b> Hours <i>hh</i> (valid -12 to +14) and minutes <i>mm</i> (valid 0 to 59 minutes)

### Show Time

<b>Description</b>	Shows the MCR-MGT Management Module's system clock.
<b>User Level</b>	Admin, Operator
<b>Syntax</b>	<code>show time</code>

### Show Timezone

<b>Description</b>	Shows the time zone settings.
<b>User Level</b>	Admin, Operator
<b>Syntax</b>	<code>show timezone</code>

# SNTP Commands

## Add SNTP

<b>Description</b>	Adds an SNTP server.
<b>User Level</b>	Admin
<b>Syntax</b>	<code>add sntp [server-1 &lt;config_host&gt;] [server-2 &lt;config_host&gt;]</code>
<b>server-1</b>	The name of the primary SNTP server from the MCR-MGT Management Module host table. Valid with <b>Unicast</b> and <b>Multicast</b> modes, although in <b>Multicast</b> mode, the MCR-MGT Management Module will only accept broadcasts from the specified host SNTP server.
<b>server-2</b>	The name of the secondary SNTP server from the MCR-MGT Management Module host table. Valid with <b>Unicast</b> and <b>Multicast</b> modes, although in <b>Multicast</b> mode, the MCR-MGT Management Module will only accept broadcasts from the specified host SNTP server.

## Delete SNTP

<b>Description</b>	Deletes an SNTP server.
<b>User Level</b>	Admin
<b>Syntax</b>	<code>delete sntp server-1 server-2</code>
<b>server-1</b>	The name of the primary SNTP server from the MCR-MGT Management Module host table. Valid with <b>Unicast</b> and <b>Multicast</b> modes, although in <b>Multicast</b> mode, the MCR-MGT Management Module will only accept broadcasts from the specified host SNTP server.
<b>server-2</b>	The name of the secondary SNTP server from the MCR-MGT Management Module host table. Valid with <b>Unicast</b> and <b>Multicast</b> modes, although in <b>Multicast</b> mode, the MCR-MGT Management Module will only accept broadcasts from the specified host SNTP server.

## Set SNTP

<b>Description</b>	Configures an SNTP server.
<b>User Level</b>	Admin
<b>Syntax</b>	<code>set sntp mode none unicast anycast multicast {keyid-1 &lt;number&gt;} [keyid-2 &lt;number&gt;] [server-1 &lt;config_host&gt;] [server-2 &lt;config_host&gt;] [server-authentication enabled disabled] [version 1 2 3 4]</code>
<b>mode</b>	<p>The SNTP mode.</p> <p><b>Data Options:</b></p> <ul style="list-style-type: none"> <li>● <b>None</b>—SNTP is turned off.</li> <li>● <b>Unicast</b>—Sends a request packet periodically to the Primary host. If communication with the Primary host fails, the request will be sent to the Secondary host.</li> <li>● <b>Multicast</b>—Listen for any broadcasts from an SNTP server and then synchronizes its internal clock to the message.</li> <li>● <b>Anycast</b>—Sends a request packet as a broadcast on the LAN to get a response from any SNTP server. The first response that is received is used to synchronize its internal clock and then operates in <b>Unicast</b> mode with that SNTP server.</li> </ul> <p><b>Default:</b> None</p>

<b>server-1</b>	The name of the primary SNTP server from the MCR-MGT Management Module host table. Valid with <b>Unicast</b> and <b>Multicast</b> modes, although in <b>Multicast</b> mode, the MCR-MGT Management Module will only accept broadcasts from the specified host SNTP server.
<b>server-2</b>	The name of the secondary SNTP server from the MCR-MGT Management Module host table. Valid with <b>Unicast</b> and <b>Multicast</b> modes, although in <b>Multicast</b> mode, the MCR-MGT Management Module will only accept broadcasts from the specified host SNTP server.
<b>Key ID</b>	Specify the key id associated with this host. This key must exist in the sntp (symmetric key) file that was downloaded to the MCR-MGT management card. <b>Valid Key ID's: 1-65534</b> <b>Note:</b> the structure for the sntp (symmetric key ) file can be found in the MCR-MGT User Guide - Appendix F (Symmetric Key File)
<b>version</b>	Version of SNTP. <b>Range:</b> 1-4 <b>Default:</b> 4

## Show SNTP

<b>Description</b>	Shows the SNTP settings.
<b>User Level</b>	Admin, Operator
<b>Syntax</b>	<b>show sntp</b>

## Show SNTP-Info

<b>Description</b>	Shows current SNTP information.
<b>User Level</b>	Admin, Operator
<b>Syntax</b>	<b>show sntp-info</b>

# Time/Date Setting Commands

## Set Date

<b>Description</b>	Sets the MCR-MGT Management Module's system clock.
<b>User Level</b>	Admin
<b>Syntax</b>	<code>set date &lt;dd/mm/yyyy&gt;</code>

## Set Summertime

<b>Description</b>	Sets the summertime clock.
<b>User Level</b>	Admin
<b>Syntax</b>	<code>set summertime [mode none fixed recurring] [name &lt;text&gt;] [offset &lt;hh:mm&gt;]</code>
<b>mode</b>	<p>You can configure the summer time to take effect:</p> <ul style="list-style-type: none"> <li>• <b>None</b>—No summer time change.</li> <li>• <b>Fixed</b>—The summer time change goes into effect at the specified time every year. For example, April 15 at 1:00 pm.</li> <li>• <b>Recurring</b>—The summer time changes goes into effect every year at same relative time. For example, on the third week in April on a Tuesday at 1:00 pm.</li> </ul> <p><b>Default:</b> None</p>
<b>&lt;name&gt;</b>	<p>The name of the configured summer time zone; this will be displayed during the summer time setting. If this parameter is not set, then the summertime feature will not work.</p> <p><b>Field Format:</b> Maximum 4 characters and minimum 3 characters (do not use angled brackets &lt;&gt;)</p>
<b>offset</b>	<p>The offset from UTC for your local time zone.</p> <p><b>Field Format:</b> Hours <i>hh</i> (valid -12 to +14) and minutes <i>mm</i> (valid 0 to 59 minutes)</p>

## Set Summertime Fixed

<b>Description</b>	Sets the summertime clock to start on the same date each year, for example, April 15 at 1:00 pm.
<b>User Level</b>	Admin
<b>Syntax</b>	<code>set summertime fixed [start-date january february ... &lt;0-31&gt;] [start-time &lt;hh:mm&gt;] [end-date january february ... &lt;0-31&gt;] [end-time &lt;hh:mm&gt;]</code>
<b>start-date</b>	The date to change to summer time and end standard time.
<b>start-time &lt;hh:mm&gt;</b>	The time to change to summertime. Valid values are 00:00 to 23:59.
<b>end-date</b>	The date to end summer time and start standard time.
<b>end-time &lt;hh:mm&gt;</b>	The time to change to standard time. <b>Range:</b> 00:00-23:59

## Set Summertime Recurring

<b>Description</b>	Sets the summertime clock to start at the same relative time each year; for example, on the third week in April on a Tuesday at 1:00 pm.
--------------------	--

<b>User Level</b>	Admin
<b>Syntax</b>	<code>set summertime recurring [start-day monday tuesday ...] [start-month january february ...] [start-time &lt;hh:mm&gt;] [start-week 1 2 3 4 5 last] [end-day monday tuesday ...] [end-month january february ...] [end-time &lt;hh:mm&gt;] [end-week 1 2 3 4 5 last]</code>
<b>start-day</b>	The day to change to summer time from standard time.
<b>start-month</b>	The month to change to summer time from standard time.
<b>start-time</b>	The time to change to summer time from standard time; uses the format hh:mm for a 24-hour clock (00:00-23:59).
<b>start-week</b>	The week to change to summer time from standard time.
<b>end-day</b>	The day to end summer time and start standard time.
<b>end-month</b>	The month to end summer time and start standard time.
<b>end-time</b>	The time to end summer time and start standard time; uses the format hh:mm for a 24-hour clock (00:00-23:59).
<b>end-week</b>	The week to end summer time and start standard time.

## Show Date

<b>Description</b>	Shows the date, according to the MCR-MGT Management Module system clock.
<b>User Level</b>	Admin, Operator
<b>Syntax</b>	<code>show date</code>

## Show Summertime

<b>Description</b>	Shows the summertime settings.
<b>User Level</b>	Admin, Operator
<b>Syntax</b>	<code>show summertime</code>



# Statistics Commands

---

## Configuration Statistics

### Show Interface

**Description** Shows IP statistics for Ethernet port.  
**User Level** Admin, Operator  
**Syntax** `show interface`

## Run-Time Statistics

### Delete Arp

**Description** Delete entries from the MCR-MGT Management Module's ARP cache. Takes effect immediately; not related to configuration.  
**User Level** Admin  
**Syntax** `delete arp`

### Show Arp

**Description** Shows the current contents of the ARP cache.  
**User Level** Admin, Operator  
**Syntax** `show arp`

### Uptime

**Description** Displays the elapsed time (in days, hours, minutes, and seconds) since the last reboot/power cycle.  
**User Level** Admin, Operator  
**Syntax** `uptime`